

 FCAR F3 Diagnostic List									Automak er			Opel	
									Softwar e			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others	
	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	-	-	-	-	-	-	
		Chassis	EPS (Electronic Power Steering)	√	√	√	-	-	-	-	-	-	
		Body	SDM (Airbag)	√	√	√	-	-	-	-	-	-	
			BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
	Corsa-C	Engine	Z 10 XEP	√	√	√	√	√	-	-	-	-	
			Z 12 XE	√	√	√	√	√	-	-	-	-	
			Z 12 XEP	√	√	√	√	√	-	-	-	-	
			Y 13 DT	√	√	√	√	√	-	-	-	-	
			Z 13 DT	√	√	√	√	√	-	-	-	-	
			Z 13 DTJ	√	√	√	√	√	-	-	-	-	
			Z 14 XE	√	√	√	√	√	√	-	-	-	
			Z 14 XEP	√	√	√	√	√	√	-	-	-	
			Z 16 SE	√	√	√	√	√	-	-	-	-	
			Z 16 YNG	√	√	√	√	√	-	-	-	-	
			Y 17 DT	√	√	√	√	√	-	-	-	-	
			Y 17 DTL	√	√	√	√	√	-	-	-	-	
			Z 17 DTH	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
		Transmissi on	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Chassis	ABS8/ESP8	√	√	√	√	√	√	√	-	-	
			ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
				Add On Heater	√	√	√	-	-	-	-	-	-
				Airbag	√	√	√	√	-	-	-	-	-
				Body Control Module	√	√	√	√	√	-	√	-	-

 爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
		Body	Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Infotainme nt System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Engine	Z 10 XEP	√	√	√	-	-	-	-	-	-	-
		A 10 XEP	√	√	√	-	-	-	-	-	-	-
		Z 12 XEP	√	√	√	√	√	√	√	-	-	
		A 12 XEL	√	√	√	-	-	-	-	-	-	
		A 12 XER	√	√	√	√	√	-	-	-	-	
		Z 13 DTE	√	√	√	-	-	-	-	-	-	
		A 13 DTE	√	√	√	-	-	-	-	-	-	
		Z 13 DTH	√	√	√	√	√	-	-	-	-	
		Z 13 DTJ	√	√	√	√	√	√	√	√	-	
		A 13 DTC	√	√	√	-	-	-	-	-	-	
		A 13 DTR	√	√	√	-	-	-	-	-	-	
		Z 14 XEP	√	√	√	√	√	√	√	-	-	
		A 14 XEL	√	√	√	-	-	-	-	-	-	
		A 14 XER	√	√	√	-	-	-	-	-	-	
		Z 16 LEL	√	√	√	-	-	-	-	-	-	
		A 16 LEL	√	√	√	-	-	-	-	-	-	
		Z 16 LER	√	√	√	-	-	-	-	-	-	
		A 16 LER	√	√	√	√	√	-	-	-	-	

 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-D		Z 17 DTR	√	√	√	-	-	-	-	-	-
			A 17 DTS	√	√	√	-	-	-	-	-	-
			Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-
		TIM (Trailer Interface Module)		√	√	√	-	-	-	-	-	-
		Immobiliser		√	√	√	√	-	-	-	-	-
		IPC (Instrument)		√	√	√	√	√	√	√	-	-
		Central Door Lock		√	√	√	√	√	-	-	-	-
		Anti Theft Warning System		√	√	√	√	√	-	-	-	-
		Heating, Ventilation and Air Cond.		√	√	√	√	-	-	-	-	-
		Wipers/Washer		√	√	√	√	-	-	-	-	-
		Interior Lighting		√	√	√	√	-	-	-	-	-
		Exterior Lighting		√	√	√	√	-	-	-	-	-
		SDM (Airbag)		√	√	√	√	-	-	-	-	-
		ECC (Electronic Climate Control)		√	√	√	-	-	-	-	-	-
		PAS (Park Pilot)		√	√	√	-	-	-	-	-	-
		EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-
		BCM (Body Control Module)		√	√	√	√	√	-	-	-	-
		Chassis	ABS / ETC	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	√	√	-	-
		Transmission	AF 13-4	√	√	√	√	√	-	-	-	-
			MTA (Easytronic)	√	√	√	-	-	-	-	-	-
			MTA (Easytronic Magneti Marelli)	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Meriva-B	Engine	Engine Control Module	√	√	√	√	√	√	-	-	Inspection/Maintenance System Info
			A13DTC 1.3 (LDV)	√	√	√	-	-	-	-	-	-
			A13DTE 1.3 (LSF)	√	√	√	-	-	-	-	-	-
			A14NEL (LUH)	√	√	√	-	-	-	-	-	-
			A14NET (LUJ)	√	√	√	-	-	-	-	-	-
			A14XER (LDD)	√	√	√	√	√	√	-	-	Inspection/Maintenance System Info
			A17DT 1.7 (LUB)	√	√	√	-	-	-	-	-	-
			A17DTC 1.7 (LUE)	√	√	√	-	-	-	-	-	-
			A17DTS 1.7 (LUD)	√	√	√	-	-	-	-	-	-
		Transmission	Transmission Control Module	√	√	√	-	-	-	-	-	-
		Chassis	Electronic Brake Control Module	√	√	√	√	√	-	-	-	-
			Electronic Power Steering Control Module	√	√	√	√	√	-	-	-	-
			Parking Brake Control Module	√	√	√	√	√	-	-	-	-
			Steering Wheel Angle Sensor Module	√	√	√	-	-	-	-	-	-
		Body	Front Seat Heating Control Module	√	√	√	-	-	-	-	-	-
			Trailer Interface Control Module	√	√	√	-	-	-	-	-	-
			Remote Heater & A/C Control Module	√	√	√	√	√	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-

 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
		Body	Parking Assist Control Module	√	√	√	√	√	-	-	-	-
			Inflatable Restraint Sensing and Diagnostic Modul	√	√	√	√	√	-	-	-	-
			Instrument Cluster	√	√	√	√	√	-	-	-	-
			Headlamp Control Module	√	√	√	-	-	-	-	-	-
		Infotainme nt System	Multimedia Player Interface Module	√	√	√	-	-	-	-	-	-
			Digital Radio Control Module	√	√	√	-	-	-	-	-	-
			Radio / Chime Alarm Control Module	√	√	√	√	√	-	-	-	-
			Mobile Telephone Control Module	√	√	√	-	-	-	-	-	-
		Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
			Y 17 DT	√	√	√	√	-	-	√	-	-
	Y 20 DTH		√	√	√	√	√	-	√	-	-	
	Y 22 DTR		√	√	√	√	√	-	-	-	-	
	Z 12 XE		√	√	√	√	√	-	-	-	-	
	Z 14 XE		√	√	√	√	√	-	-	-	-	
	Z 14 XEP		√	√	√	√	√	√	-	-	-	
	Z 16 SE		√	√	√	√	√	-	-	-	-	
	Z 16 XE		√	√	√	√	√	-	-	-	-	
	Z 16 XEP		√	√	√	√	√	-	-	-	-	
	Z 16 YNG		√	√	√	√	√	-	-	-	-	
	Z 17 DTL		√	√	√	√	√	-	-	-	-	
	Z 18 XE		√	√	√	√	√	√	-	-	-	
	Z 18 XEL		√	√	√	√	√	-	-	-	-	
	Z 20 LET		√	√	√	√	√	-	-	-	-	
	Z 22 SE		√	√	√	√	√	√	-	-	-	
	Transmissi on	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-	
		AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
2011	Astra-G	Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			Cruise Control	√	√	√	-	-	-	-	-	-	
			ESP	√	√	√	√	√	-	-	-	-	
			Electronic Power Steering	√	√	√	√	√	-	-	-	-	
		Body	Add On Heater	√	√	√	-	-	-	-	-	-	
			Airbag	√	√	√	√	-	-	-	-	-	
			Anti Theft Warning	√	√	√	√	√	-	-	-	-	
			Central Door Lock	√	√	√	√	√	-	-	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Engine Cooling Module	√	√	√	√	-	-	-	-	-	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
			Softtop Controller	√	√	√	√	√	-	-	-	-	
			Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
				Global Positioning System GPS	√	√	√	-	-	-	-	-	-
		Graphical/Colour Info Display		√	√	√	-	-	-	-	-	-	
		Info Display CART/CCRT		√	√	√	-	-	-	-	-	-	
		Multi Info Display		√	√	√	√	-	-	-	-	-	
		Radio 420		√	√	√	-	-	-	-	-	-	
		Radio 435		√	√	√	-	-	-	-	-	-	
		Radio 520		√	√	√	-	-	-	-	-	-	
		Radio 620/635/635J		√	√	√	-	-	-	-	-	-	
		Radio CAR 300		√	√	√	√	-	-	-	-	-	
		Radio CAR 400	√	√	√	√	√	-	-	-	-		
		Radio CCR 600	√	√	√	√	√	-	-	-	-		

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	A 16 LET	√	√	√	-	-	-	-	-	-
			A 16 XER	√	√	√	-	-	-	-	-	-
			A 17 DTJ	√	√	√	-	-	-	-	-	-
			A 17 DTR	√	√	√	-	-	-	-	-	-
			A 18 XER	√	√	√	-	-	-	-	-	-
			Y 13 DTH	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	-	-	-	-	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 14 XEL	√	√	√	-	-	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 XE1	√	√	√	-	-	-	-	-	-
			Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 16 XER	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	√	√	-	-
			Z 17 DTJ	√	√	√	-	-	-	-	-	-
			Z 17 DTL	√	√	√	√	√	√	√	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
			Z 18 XE	√	√	√	-	-	-	-	-	-
			Z 18 XER	√	√	√	√	√	-	√	-	-
			Z 19 DT	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Astra-H		Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LEL	√	√	√	-	-	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Transmission	AF 17-4	√	√	√	√	-	-	-	-	-	-
			AF 22-4	√	√	√	-	-	-	-	-	-	-
			AF 40-6	√	√	√	-	-	-	-	-	-	-
			MTA (Easytronic Magneti Marelli)		√	√	√	-	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)		√	√	√	√	-	-	-	-	-
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
				AHL/AFL (Headlamp Levelling)		√	√	√	-	-	-	-	-
		Anti Theft Warning System		REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	√	√	-	-
		CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-	
		Central Door Lock		√	√	√	√	√	-	-	-	-	
		EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Body	Electrohydraulic Hardtop	√	√	√	√	√	-	√	-	-
			Exterior Lighting/Turn Indicator System	√	√	√	√	√	-	-	-	-
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	√	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Interior Lighting	√	√	√	√	√	-	-	-	-
			PAS (Park Pilot)	√	√	√	√	√	-	√	-	-
			PEPS (Open&Start)	√	√	√	√	-	√	√	-	-
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			SDM (Airbag)	√	√	√	√	-	-	√	-	-
			SLM (Shift Lever Module)	√	√	√	-	-	-	-	-	-
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
		SAC (Automatic Climate Control)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
				Engine Control Module	√	√	√	√	√	-	-	-
	Fuel Pump Control Module			√	√	√	√	-	-	-	-	-
	Transmission Control Module	√		√	√	√	-	-	-	-	-	
	Electronic Brake Control Module	√		√	√	√	-	-	-	-	-	
	Parking Brake Control Module	√		√	√	√	√	-	-	-	-	
	Electronic Power Steering Control Module	√		√	√	√	-	-	-	-	-	
	Steering Column Lock Control Module	√		√	√	√	-	-	-	-	-	

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-J		Body Control Module	√	√	√	√	√	-	-	-	-
			Front Seat Heating Control Module	√	√	√	√	√	-	-	-	-
			Instrument Cluster	√	√	√	√	-	-	-	-	-
			Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	-	-	-	-
			Keyless Entry Control Module	√	√	√	√	-	-	-	-	-
			Radio	√	√	√	√	√	-	-	-	-
			Remote Heater and Air Conditioning Control Module	√	√	√	√	√	-	-	-	-
			Trailer Interface Control Module	√	√	√	√	√	-	-	-	-
	Zafira-B	Engine	A 16 XER	√	√	√	-	-	-	-	-	-
			A 16 XNT	√	√	√	-	-	-	-	-	-
			A 17 DTJ	√	√	√	√	√	√	√	√	-
			A 17 DTR	√	√	√	-	-	-	-	-	-
			A 18 XER	√	√	√	-	-	-	-	-	-
			Z 16 XE1	√	√	√	-	-	-	-	-	-
			Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 16 XER	√	√	√	-	-	-	-	-	-
			Z 16 XNT	√	√	√	-	-	-	-	-	-
			Z 16 YNG	√	√	√	-	-	-	-	-	-
			Z 18 XER	√	√	√	√	√	-	√	-	-
			Z 19 DT	√	√	√	√	-	-	-	-	-
			Z 19 DTH	√	√	√	√	√	-	√	-	-
			Z 20 LEH	√	√	√	√	√	-	-	-	-
			Z 20 LER	√	√	√	-	-	-	-	-	-
			Z 22 YH	√	√	√	√	√	-	-	-	-
		Transmissi	AF 22-4	√	√	√	-	-	-	-	-	-
			AF 40-6	√	√	√	√	√	-	-	-	-

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		on	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment System	EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
			DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
	ViVaro (PH3)	Engine	Engine Control Module	√	√	√	-	-	-	-	-	-
	Vauxhall VXR8	Engine	V8 GEN IV	√	√	√	√	√	-	-	-	-
		Transmission	Automatic Transmission	√	√	√	√	√	√	√	-	-
		Chassis	Fuel Pump Control Module	√	√	√	√	√	-	√	-	-
			EBCM (Electronic Brake Control Module)	√	√	√	√	√	-	√	-	-
			ESC (Electronic Suspension Control)	√	√	√	√	√	-	√	-	-
		Body	Immobiliser	√	√	√	√	-	√	√	-	-
			BCM (Body Control Module)	√	√	√	√	√	√	√	-	-
			RFA (Multipurpose Receiver Module)	√	√	√	√	-	√	√	-	-
			SDM (Sensing and Diagnostic Module)	√	√	√	√	-	-	√	-	-
			IPC (Instrument Panel Cluster)	√	√	√	√	√	-	-	-	-
			HVAC (Heating Ventilation and Cooling)	√	√	√	√	√	-	√	-	-
			MSM (Memory Seat and Mirrors)	√	√	√	√	√	-	√	-	-
			Park Assist	√	√	√	√	√	-	-	-	-
			AHL (Automatic Headlamp Levelling)	√	√	√	√	-	-	-	-	-
		Infotainment System	Audio System	√	√	√	√	√	-	√	-	-
			RSE (Rear Seat Entertainment)	√	√	√	√	√	-	-	-	-
		Engine Control Module		√	√	√	√	√	-	-	-	-
		Transmission Control Module		√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Insignia		Body Control Module	√	√	√	√	√	-	-	-	-
			Electronic Brake Control Module	√	√	√	√	-	-	-	-	-
			Electronic Power Steering Control Module	√	√	√	√	-	-	-	-	-
			Front Seat Heating Control Module	√	√	√	√	√	-	-	-	-
			Instrument Cluster	√	√	√	√	-	-	-	-	-
			Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	-	-	-	-
			Keyless Entry Control Module	√	√	√	√	-	-	-	-	-
			Radio	√	√	√	√	√	-	-	-	-
			Remote Heater and Air Conditioning Control Module	√	√	√	√	√	-	-	-	-
			Steering Column Lock Control Module	√	√	√	√	-	-	-	-	-
			Trailer Interface Control Module	√	√	√	√	√	-	-	-	-
	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	-	-	-	-	-	-
		Body	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	-	-	-	-	-	-
		Chassis	EPS (Electronic Power Steering)	√	√	√	-	-	-	-	-	-
		Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
			Y 17 DT	√	√	√	√	√	-	√	-	-
			Y 20 DTH	√	√	√	√	√	-	√	-	-
			Y 22 DTR	√	√	√	√	√	-	-	-	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 14 XE	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 16 XEP	√	√	√	√	√	-	-	-	-
			Z 16 YNG	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G		Z 17 DTL	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 18 XEL	√	√	√	√	√	-	-	-	-
			Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
									Software			V6.1
FCAR F3 Diagnostic List												
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	A 16 LET	√	√	√	-	-	-	-	-	-
			A 17 DTJ	√	√	√	-	-	-	-	-	-
			A 17 DTR	√	√	√	-	-	-	-	-	-
			Y 13 DTH	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 14 XEL	√	√	√	-	-	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 XE1	√	√	√	-	-	-	-	-	-
			Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 16 XER	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	√	√	-	-
			Z 17 DTJ	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Astra-H		Z 17 DTL	√	√	√	√	√	√	√	-	-	
			Z 17 DTR	√	√	√	-	-	-	-	-	-	
			Z 18 XE	√	√	√	-	-	-	-	-	-	
			Z 18 XER	√	√	√	√	√	-	√	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LEL	√	√	√	-	-	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			SLM (Shift Lever Module)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	√	-	√	-	-	
			PEPS (Open&Start)	√	√	√	√	√	√	-	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			SAC (Automatic Climate Control)		√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 17-4		√	√	√	√	-	-	-	-	-
			AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	-	-	-	-	-	-
			MTA (Easytronic Magneti Marelli)		√	√	√	-	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Astra-J		Engine Control Module	√	√	√	√	√	-	-	-	-
			Fuel Pump Control Module	√	√	√	√	-	-	-	-	-
			Transmission Control Module	√	√	√	√	-	-	-	-	-
			Electronic Brake Control Module	√	√	√	√	-	-	-	-	-
			Parking Brake Control Module	√	√	√	√	√	-	-	-	-
			Electronic Power Steering Control Module	√	√	√	√	-	-	-	-	-
			Steering Column Lock Control Module	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-
			Front Seat Heating Control Module	√	√	√	√	√	-	-	-	-
			Instrument Cluster	√	√	√	√	-	-	-	-	-
			Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	-	-	-	-
			Keyless Entry Control Module	√	√	√	√	-	-	-	-	-
			Radio	√	√	√	√	√	-	-	-	-
			Remote Heater and Air Conditioning Control Module	√	√	√	√	√	-	-	-	-
			Trailer Interface Control Module	√	√	√	√	√	-	-	-	-
			Y 13 DT	√	√	√	√	√	-	-	-	-
			Y 17 DT	√	√	√	√	-	-	√	-	-
			Y 17 DTL	√	√	√	√	√	-	-	-	-
			Z 10 XEP	√	√	√	√	√	-	-	-	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DT	√	√	√	√	√	-	-	-	-

 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Corsa-C	Engine	Z 13 DTJ	√	√	√	√	√	-	-	-	-	
			Z 14 XE	√	√	√	√	√	-	-	-	-	
			Z 14 XEP	√	√	√	√	√	√	-	-	-	
			Z 16 SE	√	√	√	√	√	-	-	-	-	
			Z 16 YNG	√	√	√	√	√	-	-	-	-	
			Z 17 DTH	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
		Body	Add On Heater	√	√	√	-	-	-	-	-	-	
			Airbag	√	√	√	√	-	-	-	-	-	
			Body Control Module	√	√	√	√	√	-	√	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			ABS8/ESP8	√	√	√	√	√	-	√	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-	
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-	
				Z 10 XEP	√	√	√	-	-	-	-	-	-
				A 10 XEP	√	√	√	-	-	-	-	-	-
				Z 12 XEP	√	√	√	√	√	√	√	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-D	Engine	A 12 XEL	√	√	√	√	√	√	√	-	-
			A 12 XER	√	√	√	√	√	-	-	-	-
			Z 13 DTE	√	√	√	-	-	-	-	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	√	√	√	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			A 14 XEL	√	√	√	√	√	√	√	-	-
			A 14 XER	√	√	√	√	√	√	√	-	-
			Z 16 LEL	√	√	√	-	-	-	-	-	-
			A 16 LEL	√	√	√	-	-	-	-	-	-
			Z 16 LER	√	√	√	-	-	-	-	-	-
			A 16 LER	√	√	√	√	√	-	-	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
			A 17 DTS	√	√	√	-	-	-	-	-	-
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-
			Anti Theft Warning System	√	√	√	√	√	-	-	-	-
			BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			Exterior Lighting	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	√	√	√	√	-	-	-	-	-
			IPC (Instrument)	√	√	√	√	√	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Interior Lighting	√	√	√	√	-	-	-	-	-
			PAS (Park Pilot)	√	√	√	-	-	-	-	-	-

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
2010			SDM (Airbag)	√	√	√	√	-	-	-	-	-
			TIM (Trailer Interface Module)	√	√	√	-	-	-	-	-	-
			Wipers/Washer	√	√	√	√	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	√	√	-	-
		Transmission	AF 13-4	√	√	√	√	√	-	-	-	-
			MTA (Easytronic Magneti Marelli)	√	√	√	-	-	-	-	-	-
			MTA (Easytronic)	√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
		Engine	Engine Control Module	√	√	√	√	√	√	-	-	Inspection/Maintenance System Info
			A13DTC 1.3 (LDV)	√	√	√	-	-	-	-	-	-
			A13DTE 1.3 (LSF)	√	√	√	-	-	-	-	-	-
			A14NEL (LUH)	√	√	√	-	-	-	-	-	-
			A14NET (LUJ)	√	√	√	-	-	-	-	-	-
			A14XER (LDD)	√	√	√	√	√	√	-	-	Inspection/Maintenance System Info
			A17DT 1.7 (LUB)	√	√	√	-	-	-	-	-	-
			A17DTC 1.7 (LUE)	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Meriva-B		A17DTS 1.7 (LUD)	√	√	√	-	-	-	-	-	-
		Transmission	Transmission Control Module	√	√	√	-	-	-	-	-	-
		Chassis	Electronic Brake Control Module	√	√	√	√	√	-	-	-	-
			Electronic Power Steering Control Module	√	√	√	√	√	-	-	-	-
			Parking Brake Control Module	√	√	√	√	√	-	-	-	-
			Steering Wheel Angle Sensor Module	√	√	√	-	-	-	-	-	-
			Front Seat Heating Control Module	√	√	√	-	-	-	-	-	-
		Body	Trailer Interface Control Module	√	√	√	-	-	-	-	-	-
			Remote Heater & A/C Control Module	√	√	√	√	√	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-
			Parking Assist Control Module	√	√	√	√	√	-	-	-	-
			Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	-	-	-	-
			Instrument Cluster	√	√	√	√	√	-	-	-	-
			Headlamp Control Module	√	√	√	-	-	-	-	-	-
			Multimedia Player Interface Module	√	√	√	-	-	-	-	-	-
			Digital Radio Control Module	√	√	√	-	-	-	-	-	-
		Radio / Chime Alarm Control Module	√	√	√	√	√	-	-	-	-	
		Mobile Telephone Control Module	√	√	√	-	-	-	-	-	-	
		Engine	Y 13 DT	√	√	√	√	√	-	-	-	-
			Y 17 DT	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-

爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Meriva		Z 16 XEP	√	√	√	√	√	-	-	-	-	
			Z 17 DT	√	√	√	-	-	-	-	-	-	
			Z 17 DTH	√	√	√	√	√	-	-	-	-	
			Z 17 DTR	√	√	√	-	-	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-	
			Add On Heater	√	√	√	-	-	-	-	-	-	
			Airbag	√	√	√	√	-	-	-	-	-	
			Body Control Module	√	√	√	√	√	-	√	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-	
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-	
				A 17 DTJ	√	√	√	√	√	√	√	√	-
				A 17 DTR	√	√	√	-	-	-	-	-	-
				Z 16 XE1	√	√	√	-	-	-	-	-	-
				Z 16 XEP	√	√	√	√	√	√	√	-	-

爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Zafira-B	Engine	Z 16 XER	√	√	√	-	-	-	-	-	-	
			Z 16 XNT	√	√	√	-	-	-	-	-	-	
			Z 16 YNG	√	√	√	-	-	-	-	-	-	
			Z 18 XER	√	√	√	√	√	-	√	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	-	-	-	-	-	
			PEPS (Open&Start)	√	√	√	√	-	√	√	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			SDM (Airbag)	√	√	√	√	-	-	√	-	-	
			SLM (Shift Lever Module)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Anti Inert Warning System	IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	
				PEPS (Open&Start)	√	√	√	√	-	√	√	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			SAC (Automatic Climate Control)		√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-				
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	√	√	-	-	-	-
			MTA (Easytronic)		√	√	√	√	√	-	-	-	-
		Infotainment System	EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
	Insignia		Engine Control Module	√	√	√	√	√	-	-	-	-
			Transmission Control Module	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-
			Electronic Brake Control Module	√	√	√	√	-	-	-	-	-
			Electronic Power Steering Control Module	√	√	√	√	-	-	-	-	-
			Front Seat Heating Control Module	√	√	√	√	√	-	-	-	-
			Instrument Cluster	√	√	√	√	-	-	-	-	-
			Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	-	-	-	-
			Keyless Entry Control Module	√	√	√	√	-	-	-	-	-
			Radio	√	√	√	√	√	-	-	-	-
			Remote Heater and Air Conditioning Control Module	√	√	√	√	√	-	-	-	-
			Steering Column Lock Control Module	√	√	√	√	-	-	-	-	-
			Trailer Interface Control Module	√	√	√	√	√	-	-	-	-
	Vivaro	Engine	F9Q 760/762 (1.9l)	√	√	√	√	√	-	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	√	√	-	-
		Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
		Engine	G9U 750 (2.5l)	√	√	√	-	-	-	-	-	-
			G9U 754 (2.5l)	√	√	√	-	-	-	-	-	-

 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Movano	Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	-	-	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	-	-	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-
		Transmissi on	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
	Captiva (Long Body)	Engine	2.0 L (Diesel)	√	√	√	-	-	-	-	-	-
			Z 24 XE	√	√	√	-	-	-	-	-	-
			Z 32 SE	√	√	√	√	√	-	-	-	-
		Body	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-
			IPC (Instrument)	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
			RFA (Multipurpose Receiver Module)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	-	-	-	-	-	-
			XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	-	-	-	-
		Transmissi on	Automatic Transmission	√	√	√	-	-	-	-	-	-
			TCCM (Transfer Case Control Module)	√	√	√	-	-	-	-	-	-
		Engine	2.0 L (Diesel)	√	√	√	-	-	-	-	-	-
			Z 24 XE	√	√	√	-	-	-	-	-	-
			Z 32 SE	√	√	√	-	-	-	-	-	-
			AHL (Automatic Headlamp Levelling)	√	√	√	-	-	-	-	-	-
			BCM (Body Control Module)	√	√	√	-	-	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Antara, Captiva (Short Body)	Body	Anti Theft Warning System	XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
			BCM (Body Control Module)		√	√	√	-	-	-	-	-	-
			Central Door Lock	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	-	-	-	-	-	-
			Exterior Lighting/Turn Indicator	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			HVAC (Heating Ventilation and Cooling)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			IPC (Instrument)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobiliser	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			RFA (Multipurpose Receiver)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SLM (Shift Lever Module)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
			Wipers/Washer	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			XBCM (Auxiliary Body Control Module)		√	√	√	-	-	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)		√	√	√	-	-	-	-	-	-
		Transmission	Automatic Transmission		√	√	√	-	-	-	-	-	-
			TCCM (Transfer Case Control Module)		√	√	√	-	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Agila-B	Engine	D13A / Z 13 DTJ	√	√	√	-	-	-	-	-	-
		Body	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	-	-	-	-	-	-
		Chassis	EPS (Electronic Power Steering)	√	√	√	-	-	-	-	-	-
	Engine	C 16 SEL	√	√	√	√	√	-	√	√	-	
		Y 17 DT	√	√	√	√	-	-	√	-	-	
		Y 20 DTH	√	√	√	√	√	-	√	-	-	
		Y 22 DTR	√	√	√	√	√	-	-	-	-	
		Z 12 XE	√	√	√	√	√	-	-	-	-	
		Z 14 XE	√	√	√	√	√	-	-	-	-	
		Z 14 XEP	√	√	√	√	√	√	-	-	-	
		Z 16 SE	√	√	√	√	√	-	-	-	-	
		Z 16 XE	√	√	√	√	√	-	-	-	-	
		Z 16 XEP	√	√	√	√	√	-	-	-	-	
		Z 16 YNG	√	√	√	√	√	-	-	-	-	
		Z 17 DTL	√	√	√	√	√	-	-	-	-	
		Z 18 XE	√	√	√	√	√	√	-	-	-	
		Z 18 XEL	√	√	√	√	√	-	-	-	-	
		Z 20 LET	√	√	√	√	√	-	-	-	-	
		Z 22 SE	√	√	√	√	√	√	-	-	-	
			Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
	Anti Theft Warning		√	√	√	√	√	-	-	-	-	

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G	Body	Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automak er			Opel
									Softwar e			V6.1
FCAR F3 Diagnostic List												
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	A 16 LET	√	√	√	-	-	-	-	-	-
			A 17 DTJ	√	√	√	-	-	-	-	-	-
			A 17 DTR	√	√	√	-	-	-	-	-	-
			Y 13 DTH	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 14 XEL	√	√	√	-	-	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 XE1	√	√	√	-	-	-	-	-	-
			Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 16 XER	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	√	√	-	-
			Z 17 DTJ	√	√	√	-	-	-	-	-	-
			Z 17 DTL	√	√	√	√	√	√	√	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
			Z 18 XE	√	√	√	-	-	-	-	-	-
			Z 18 XER	√	√	√	√	√	-	√	-	-
			Z 19 DT	√	√	√	√	-	-	-	-	-
			Z 19 DTH	√	√	√	√	√	-	√	-	-
			Z 20 LEH	√	√	√	√	√	-	-	-	-
			Z 20 LEL	√	√	√	-	-	-	-	-	-

 爱夫卡										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Astra-H		Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			SLM (Shift Lever Module)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	√	-	√	-	-	
			PEPS (Open&Start)	√	√	√	√	√	√	-	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
		CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-	
					PEPS (Open&Start)	√	√	√	√	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			SAC (Automatic Climate Control)		√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 17-4		√	√	√	√	-	-	-	-	-
			AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	-	-	-	-	-	-
			MTA (Easytronic Magneti Marelli)		√	√	√	-	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-
			Engine Control Module		√	√	√	√	√	-	-	-	-
			Fuel Pump Control Module		√	√	√	√	-	-	-	-	-
			Transmission Control Module		√	√	√	√	-	-	-	-	-
			Electronic Brake Control Module		√	√	√	√	-	-	-	-	-
			Parking Brake Control Module		√	√	√	√	√	-	-	-	-
			Electronic Power Steering Control Module		√	√	√	√	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel	
									Softwar e			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others	
	Astra-J		Steering Column Lock Control Module	√	√	√	√	-	-	-	-	-	
			Body Control Module	√	√	√	√	√	-	-	-	-	
			Front Seat Heating Control Module	√	√	√	√	√	-	-	-	-	
			Instrument Cluster	√	√	√	√	-	-	-	-	-	
			Inflatable Restraint Sensing and Diagnostic Module	√	√	√	√	√	-	-	-	-	
			Keyless Entry Control Module	√	√	√	√	-	-	-	-	-	
			Radio	√	√	√	√	√	-	-	-	-	
			Remote Heater and Air Conditioning Control Module	√	√	√	√	√	-	-	-	-	
	Corsa-C	Engine		Trailer Interface Control Module	√	√	√	√	√	-	-	-	-
				Y 13 DT	√	√	√	√	√	-	-	-	-
				Y 17 DT	√	√	√	√	-	-	√	-	-
				Y 17 DTL	√	√	√	√	√	-	-	-	-
				Z 10 XEP	√	√	√	√	√	-	-	-	-
				Z 12 XE	√	√	√	√	√	-	-	-	-
				Z 12 XEP	√	√	√	√	√	-	-	-	-
				Z 13 DT	√	√	√	√	√	-	-	-	-
				Z 13 DTJ	√	√	√	√	√	-	-	-	-
				Z 14 XE	√	√	√	√	√	-	-	-	-
				Z 14 XEP	√	√	√	√	√	√	-	-	-
				Z 16 SE	√	√	√	√	√	-	-	-	-
				Z 16 YNG	√	√	√	√	√	-	-	-	-
				Z 17 DTH	√	√	√	√	√	-	-	-	-
		Z 18 XE	√	√	√	√	√	√	-	-	-		
				Add On Heater	√	√	√	-	-	-	-	-	-
				Airbag	√	√	√	√	-	-	-	-	-
				Body Control Module	√	√	√	√	√	-	√	-	-

爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Body	Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			ABS8/ESP8	√	√	√	√	√	-	√	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-	
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-	
			Engine	Z 10 XEP	√	√	√	-	-	-	-	-	-
				Z 12 XEP	√	√	√	√	√	√	√	-	-
				Z 13 DTH	√	√	√	√	√	-	-	-	-
				Z 13 DTI	√	√	√	-	-	-	-	-	-
	Z 13 DTJ			√	√	√	√	√	√	√	√	-	
	Z 13 DTR			√	√	√	-	-	-	-	-	-	
	Z 14 XEP			√	√	√	√	√	√	√	-	-	
	Z 16 LEL			√	√	√	-	-	-	-	-	-	
	Z 16 LER			√	√	√	-	-	-	-	-	-	
	Z 17 DTR			√	√	√	-	-	-	-	-	-	
			AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-	
			Anti Theft Warning System	√	√	√	√	√	-	-	-	-	
			BCM (Body Control Module)	√	√	√	√	√	-	-	-	-	

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
2009	Corsa-D	Body	Central Door Lock	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			Exterior Lighting	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	√	√	√	√	-	-	-	-	-
			IPC (Instrument)	√	√	√	√	√	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Interior Lighting	√	√	√	√	-	-	-	-	-
			PAS (Park Pilot)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	√	-	-	-	-	-
		TIM (Trailer Interface Module)	√	√	√	-	-	-	-	-	-	
		Wipers/Washer	√	√	√	√	-	-	-	-	-	
		Chassis	ABS/ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	√	√	-	-
		Transmission	AF 13-4	√	√	√	√	√	-	-	-	-
			MTA (Easytronic Magneti Marelli)	√	√	√	-	-	-	-	-	-
			MTA (Easytronic)	√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
			Y 13 DT	√	√	√	√	√	-	-	-	-
			Y 17 DT	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-

 爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Meriva	Engine	Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 16 XEP	√	√	√	√	√	-	-	-	-
			Z 17 DT	√	√	√	-	-	-	-	-	-
			Z 17 DTH	√	√	√	√	√	-	-	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-
			Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmissi on	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainme nt System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Engine	Z 13 DT	√	√	√	√	√	-	-	-	-	
		Z 14 XEP	√	√	√	√	√	√	-	-	-	
		Z 18 XE	√	√	√	√	√	√	-	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Tigra-B	Body	Airbag	√	√	√	√	-	-	-	-	-	
			Body Control Module	√	√	√	√	√	-	√	-	-	
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-	
	EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-		
		Engine	A 17 DTJ	√	√	√	√	√	√	√	√	-	
			A 17 DTR	√	√	√	-	-	-	-	-	-	
			Z 16 XE1	√	√	√	-	-	-	-	-	-	
			Z 16 XEP	√	√	√	√	√	√	√	-	-	
			Z 16 XER	√	√	√	-	-	-	-	-	-	
			Z 16 XNT	√	√	√	-	-	-	-	-	-	
			Z 16 YNG	√	√	√	-	-	-	-	-	-	
			Z 18 XER	√	√	√	√	√	-	√	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
				AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
		EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-	

									Automak er			Opel		
FCAR F3 Diagnostic List									Softwar e			V6.1		
Menu			Function											
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others		
	Zafira-B	Body	IPC ECU (Instrument Control Unit)		√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)		√	√	√	√	-	-	-	-	-	
			PEPS (Open&Start)		√	√	√	√	-	√	√	-	-	-
			REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	-
			SDM (Airbag)		√	√	√	√	-	-	√	-	-	-
			SLM (Shift Lever Module)		√	√	√	√	√	-	-	-	-	-
			UEC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-	-
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	-
			Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	√	√	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-	-
			SAC (Automatic Climate Control)		√	√	√	√	√	-	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-				
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	√	√	-	-	-	-
			MTA (Easytronic)		√	√	√	√	√	-	-	-	-
		Infotainment System	EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-
			DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-
	Insignia		Engine Control Module		√	√	√	√	√	-	-	-	-
			Transmission Control Module		√	√	√	√	-	-	-	-	-
			Body Control Module		√	√	√	√	√	-	-	-	-
			Electronic Brake Control Module		√	√	√	√	-	-	-	-	-
			Electronic Power Steering Control Module		√	√	√	√	-	-	-	-	-
			Front Seat Heating Control Module		√	√	√	√	√	-	-	-	-
			Instrument Cluster		√	√	√	√	-	-	-	-	-
			Inflatable Restraint Sensing and Diagnostic Module		√	√	√	√	√	-	-	-	-
			Keyless Entry Control Module		√	√	√	√	-	-	-	-	-
			Radio		√	√	√	√	√	-	-	-	-

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Remote Heater and Air Conditioning Control Module		√	√	√	√	√	-	-	-	-
		Steering Column Lock Control Module		√	√	√	√	-	-	-	-	-
		Trailer Interface Control Module		√	√	√	√	√	-	-	-	-
	Vivaro	Engine	F9Q 760/762 (1.9l)	√	√	√	√	√	-	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	√	√	-	-
		Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
	Movano	Engine	G9U 750 (2.5l)	√	√	√	-	-	-	-	-	-
			G9U 754 (2.5l)	√	√	√	-	-	-	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	-	-	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	-	-	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-
		Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
		Engine	V8 GEN IV	√	√	√	√	√	-	-	-	-
		Transmission	Automatic Transmission	√	√	√	√	√	√	√	-	-
		EBCM (Electronic Brake Control Module)		√	√	√	√	√	-	-	-	-

 爱夫卡									Automak er			Opel
FCAR F3 Diagnostic List									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Vauxhall VXR8	Chassis	ESC (Electronic Suspension Control)	√	√	√	√	√	-	√	-	-
		Body	Immobiliser	√	√	√	√	-	√	√	-	-
			BCM (Body Control Module)	√	√	√	√	√	√	√	-	-
			IPC (Instrument Panel Cluster)	√	√	√	√	√	-	-	-	-
			SDM (Sensing and Diagnostic Module)	√	√	√	√	-	-	√	-	-
			HVAC (Heating Ventilation and Cooling)	√	√	√	√	√	-	√	-	-
			RFA (Remote Function Actuator)	√	√	√	√	-	√	√	-	-
			MSM (Memory Seat and Mirrors)	√	√	√	√	√	-	√	-	-
			Park Assist	√	√	√	√	√	-	-	-	-
			AHL (Automatic Headlamp Levelling)	√	√	√	√	√	√	√	-	-
		Infotainment System	Audio System	√	√	√	√	√	-	√	-	-
			Driver Information Display	√	√	√	√	-	-	-	-	-
			RSE (Rear Seat Entertainment)	√	√	√	√	√	-	-	-	-
			Telematics	√	√	√	√	√	-	√	-	-
	Captiva (Long Body)		Engine	2.0 L (Diesel)	√	√	√	-	-	-	-	-
		Z 24 XE		√	√	√	-	-	-	-	-	-
		Z 32 SE		√	√	√	√	√	-	-	-	-
		Body	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-
			IPC (Instrument)	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
			RFA (Multipurpose Receiver Module)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	-	-	-	-	-	-
			XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	-	-	-	-
		Transmissi	Automatic Transmission	√	√	√	-	-	-	-	-	-

 FCAR F3 Diagnostic List									Automak er			Opel	
									Softwar e			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others	
Antara, Captiva (Short Body)		on	TCCM (Transfer Case Control Module)	√	√	√	-	-	-	-	-	-	
		Engine	2.0 L (Diesel)	√	√	√	-	-	-	-	-	-	
			Z 24 XE	√	√	√	-	-	-	-	-	-	
			Z 32 SE	√	√	√	-	-	-	-	-	-	
			AHL (Automatic Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
		Body	Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
			BCM (Body Control Module)		√	√	√	-	-	-	-	-	-
			Central Door Lock	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	-	-	-	-	-	-
			Exterior Lighting/Turn Indicator	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			HVAC (Heating Ventilation and Cooling)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			IPC (Instrument)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobiliser	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			RFA (Multipurpose Receiver	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SLM (Steering Lock Module)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			SLM (Shift Lever Module)	XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
			Wipers/Washer	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			XBCM (Auxiliary Body Control Module)		√	√	√	-	-	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)		√	√	√	-	-	-	-	-	-
		Transmission	Automatic Transmission		√	√	√	-	-	-	-	-	-
			TCCM (Transfer Case Control Module)		√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)		√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)		√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-
	Agila-B	Engine	D13A / Z 13 DTJ		√	√	√	-	-	-	-	-	-
		Body	BCM (Body Control Module)		√	√	√	-	-	-	-	-	-
			SDM (Airbag)		√	√	√	-	-	-	-	-	-
		Chassis	EPS (Electronic Power Steering)		√	√	√	-	-	-	-	-	-
		Engine	C 16 SEL		√	√	√	√	√	-	√	√	-
			Y 17 DT		√	√	√	√	-	-	√	-	-
			Y 20 DTH		√	√	√	√	√	-	√	-	-
			Y 22 DTR		√	√	√	√	√	-	-	-	-
			Z 12 XE		√	√	√	√	√	-	-	-	-
			Z 14 XE		√	√	√	√	√	-	-	-	-
			Z 14 XEP		√	√	√	√	√	√	-	-	-
			Z 16 SE		√	√	√	√	√	-	-	-	-
			Z 16 XE		√	√	√	√	√	-	-	-	-
			Z 16 XEP		√	√	√	√	√	-	-	-	-
			Z 16 YNG		√	√	√	√	√	-	-	-	-
			Z 17 DTL		√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G		Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 18 XEL	√	√	√	√	√	-	-	-	-
			Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
	Triple Info Display	√	√	√	√	-	-	-	-	-		
		Engine	A 17 DTJ	√	√	√	-	-	-	-	-	-
			A 17 DTR	√	√	√	-	-	-	-	-	-
			Y 13 DTH	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 14 XEL	√	√	√	-	-	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 XE1	√	√	√	-	-	-	-	-	-
			Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 16 XER	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	√	√	-	-
			Z 17 DTJ	√	√	√	-	-	-	-	-	-
			Z 17 DTL	√	√	√	√	√	√	√	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Astra-H		Z 18 XE	√	√	√	-	-	-	-	-	-	
			Z 18 XER	√	√	√	√	√	-	√	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LEL	√	√	√	-	-	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			SLM (Shift Lever Module)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	√	-	√	-	-	
			PEPS (Open&Start)	√	√	√	√	√	√	-	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	-	-	-	-
				ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
				SAC (Automatic Climate Control)	√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 17-4		√	√	√	√	-	-	-	-	-
			AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	-	-	-	-	-	-
			MTA (Easytronic Magneti Marelli)		√	√	√	-	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-C	Engine	Y 13 DT	√	√	√	√	√	-	-	-	-
			Y 17 DT	√	√	√	√	-	-	√	-	-
			Y 17 DTL	√	√	√	√	√	-	-	-	-
			Z 10 XEP	√	√	√	√	√	-	-	-	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DT	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	-	-	-	-
			Z 14 XE	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 YNG	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	Instrument	√	√	√	√	√	-	-	-	-
			ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			ABS8/ESP8	√	√	√	√	√	-	√	-	-
		Transmission	Electronic Power Steering	√	√	√	√	-	-	-	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-

 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Corsa-D	Engine	Z 10 XEP	√	√	√	-	-	-	-	-	-
			Z 12 XEP	√	√	√	√	√	√	√	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	√	√	√	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 LEL	√	√	√	-	-	-	-	-	-
			Z 16 LER	√	√	√	-	-	-	-	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-
			Anti Theft Warning System	√	√	√	√	√	-	-	-	-
			BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			Exterior Lighting	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	√	√	√	√	-	-	-	-	-
			IPC (Instrument)	√	√	√	√	√	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Interior Lighting	√	√	√	√	-	-	-	-	-
			PAS (Park Pilot)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	√	-	-	-	-	-
			TIM (Trailer Interface Module)	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Chassis	Wipers/Washer	√	√	√	√	-	-	-	-	-
			ABS/ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	√	√	-	-
		Transmission	AF 13-4	√	√	√	√	√	-	-	-	-
			MTA (Easytronic Magneti Marelli)	√	√	√	-	-	-	-	-	-
			MTA (Easytronic)	√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Meriva		Engine	Y 13 DT	√	√	√	√	√	-	-	-
		Y 17 DT		√	√	√	√	√	-	-	-	-
		Z 13 DTJ		√	√	√	√	√	-	-	-	-
		Z 14 XEP		√	√	√	√	√	√	-	-	-
		Z 16 LET		√	√	√	-	-	-	-	-	-
		Z 16 SE		√	√	√	√	√	-	-	-	-
		Z 16 XE		√	√	√	√	√	-	-	-	-
		Z 16 XEP		√	√	√	√	√	-	-	-	-
		Z 17 DT		√	√	√	-	-	-	-	-	-
		Z 17 DTH		√	√	√	√	√	-	-	-	-
		Z 17 DTR		√	√	√	-	-	-	-	-	-
		Z 18 XE		√	√	√	√	√	√	-	-	-
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-
			Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
2008			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Tigra-B	Engine	Z 13 DT	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
				A 17 DTJ	√	√	√	√	√	√	√	√

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Engine	A 17 DTR	√	√	√	-	-	-	-	-	-	
			Z 16 XE1	√	√	√	-	-	-	-	-	-	
			Z 16 XEP	√	√	√	√	√	√	√	-	-	
			Z 16 XER	√	√	√	-	-	-	-	-	-	
			Z 16 YNG	√	√	√	-	-	-	-	-	-	
			Z 18 XER	√	√	√	√	√	-	√	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	-	-	-	-	-	
			PEPS (Open&Start)	√	√	√	√	-	√	√	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			SDM (Airbag)	√	√	√	√	-	-	√	-	-	
			SLM (Shift Lever Module)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-

										Automaker			Opel	
FCAR F3 Diagnostic List										Software			V6.1	
Menu			Function											
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Zafira-B		Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
				IPC (Instrument)	√	√	√	√	√	-	-	-	-	
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-		
				PEPS (Open&Start)	√	√	√	√	-	√	√	-	-	
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-	
		SAC (Automatic Climate Control)		√	√	√	√	√	-	-	-	-		
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-					
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-	
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-	
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-	
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-	
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-	
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-	
		Transmission	AF 22-4		√	√	√	-	-	-	-	-	-	
			AF 40-6		√	√	√	√	√	-	-	-	-	
			MTA (Easytronic)		√	√	√	√	√	-	-	-	-	
				EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-

 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	√	√	-	-	-	-	
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-	
			DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
		Engine	Engine Cooling	√	√	√	√	-	-	-	-	-	
			Y 20 DTH	√	√	√	√	√	-	-	-	-	
			Y 22 DTR	√	√	√	√	√	-	-	-	-	
			Z 16 XE	√	√	√	√	√	-	-	-	-	
			Z 16 XEP	√	√	√	-	-	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	√	-	
			Z 18 XER	√	√	√	√	√	√	-	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	-	-	-	
			Z 20 NET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	√	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
			Z 28 NEH	√	√	√	-	-	-	-	-	-	
			Z 28 NEL	√	√	√	√	-	-	√	-	-	
			Z 28 NET	√	√	√	-	-	-	-	-	-	
			Z 30 DT	√	√	√	-	-	-	-	-	-	
			Z 32 SE	√	√	√	√	-	-	-	-	-	
		Additional Heating	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-	
			BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-
					PDM (Passenger Door Module)	√	√	√	√	-	-	-	-

 爱夫卡										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-C / Signum	Body		REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			BCM (Body Control Module)		√	√	√	-	-	-	-	-	-
			CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-
			IPC (Instrument)		√	√	√	√	√	-	-	-	-
			Central Door Lock	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			DDM (Driver Door Module)		√	√	√	√	-	-	-	-	-
			DSM (Driver Seat Module)		√	√	√	√	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-
			Electric Adjustable Mirrors	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			Electrical Horn	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Electronic Seat Memory/Seat Heating	REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			Exterior Lighting	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobiliser	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	IPC (Instrument)	√	√	√	√	√	-	-	-	-
				SDM (Airbag)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			PAS (Park Pilot)	√	√	√	√	-	-	-	-	-	
			PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-	
			Power Window Lift	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-	
			SAC (Automatic Climate Control)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag; Sensing&Diagnostic Module)	√	√	√	√	-	-	-	-	-	
			SLM (Shift Lever Module)	√	√	√	√	-	-	-	-	-	
			SRM (Sun Roof Module)	√	√	√	√	-	-	-	-	-	
			Turn Indication	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			UEC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-	
		Wipers/Washer	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-	
		Chassis	ABS/TC/ESP	√	√	√	√	√	-	-	-	-	
			CDC (Continuous Damping Control)	√	√	√	-	-	-	-	-	-	
			EHPS (Electrohydraulic Power Steering)	√	√	√	√	-	-	-	-	-	
			TPMS (Tyre Pressure Monitoring System)	√	√	√	-	-	-	-	-	-	
			Electronic Cruise Control	Engine	√	√	√	√	-	-	-	-	-
		Transmission	AF 23-5/33-5/40-6	√	√	√	√	√	-	-	-	-	
			CVTronic	√	√	√	-	-	-	-	-	-	
			MTA (Easytronic)	√	√	√	-	-	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
			DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-	
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-	
			Engine	F9Q 760/762 (1.9l)	√	√	√	√	√	-	-	-	-
				Add On Heater	√	√	√	-	-	-	-	-	-

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vivaro	Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	√	√	-	-
		Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
	Movano	Engine	G9U 750 (2.5l)	√	√	√	-	-	-	-	-	-
			G9U 754 (2.5l)	√	√	√	-	-	-	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	-	-	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	-	-	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-
		Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
	Vauxhall	Engine	V8 GEN IV	√	√	√	√	√	-	-	-	-
		Transmission	Automatic Transmission	√	√	√	√	√	√	√	-	-
		Chassis	EBCM (Electronic Brake Control Module)	√	√	√	√	√	-	-	-	-
			ESC (Electronic Suspension Control)	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	√	√	-	-
			BCM (Body Control Module)	√	√	√	√	√	√	√	-	-
			IPC (Instrument Panel Cluster)	√	√	√	√	√	-	-	-	-
			SDM (Sensing and Diagnostic Module)	√	√	√	√	-	-	√	-	-

 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	VXR8	Body	HVAC (Heating Ventilation and Cooling)	√	√	√	√	√	-	√	-	-	
			RFA (Remote Function Actuator)	√	√	√	√	-	√	√	-	-	
			MSM (Memory Seat and Mirrors)	√	√	√	√	√	-	√	-	-	
			Park Assist	√	√	√	√	√	-	-	-	-	
			AHL (Automatic Headlamp Levelling)	√	√	√	√	√	√	√	-	-	
		Infotainment System	Audio System	√	√	√	√	√	-	√	-	-	
			Driver Information Display	√	√	√	√	-	-	-	-	-	
			RSE (Rear Seat Entertainment)	√	√	√	√	√	-	-	-	-	
	Captiva (Long Body)	Engine	Telematics	√	√	√	√	√	-	√	-	-	
			2.0 L (Diesel)	√	√	√	-	-	-	-	-	-	
			Z 24 XE	√	√	√	-	-	-	-	-	-	
		Body	Z 32 SE	√	√	√	√	√	-	-	-	-	
			BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-	
			IPC (Instrument)	√	√	√	-	-	-	-	-	-	
			Immobiliser	√	√	√	-	-	-	-	-	-	
			RFA (Multipurpose Receiver Module)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag)	√	√	√	-	-	-	-	-	-	
			XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-	
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	-	-	-	-	
		Transmission	Automatic Transmission	√	√	√	-	-	-	-	-	-	
			TCCM (Transfer Case Control Module)	√	√	√	-	-	-	-	-	-	
			Engine	2.0 L (Diesel)	√	√	√	-	-	-	-	-	-
				Z 24 XE	√	√	√	-	-	-	-	-	-
				Z 32 SE	√	√	√	-	-	-	-	-	-
				AHL (Automatic Headlamp Levelling)	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List										Automak er			Opel
										Softwar e			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Antara, Captiva (Short Body)	Body	Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
			BCM (Body Control Module)		√	√	√	-	-	-	-	-	-
			Central Door Lock	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	-	-	-	-	-	-
			Exterior Lighting/Turn Indicator	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			HVAC (Heating Ventilation and Cooling)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			IPC (Instrument)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobiliser	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			RFA (Multipurpose Receiver	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			SLM (Shift Lever Module)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-
			Wipers/Washer	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			XBCM (Auxiliary Body Control Module)		√	√	√	-	-	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)		√	√	√	-	-	-	-	-	-
		Transmissi	Automatic Transmission		√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel		
FCAR F3 Diagnostic List									Software			V6.1		
Menu			Function											
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others		
		on	TCCM (Transfer Case Control Module)	√	√	√	-	-	-	-	-	-		
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-		
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-		
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-		
	Agila-B	Engine	Z 10 XEP	√	√	√	√	√	-	-	-	-		
			Z 12 XE	√	√	√	√	√	-	-	-	-		
			Z 12 XEP	√	√	√	√	√	-	-	-	-		
			Z 13 DT	√	√	√	√	√	-	-	-	-		
		Body	Airbag	√	√	√	√	-	-	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	-	
		Chassis	ABS	√	√	√	√	√	-	√	-	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	-	
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-	-	
				Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
					Y 17 DT	√	√	√	√	-	-	√	-	-
					Y 20 DTH	√	√	√	√	√	-	√	-	-
Y 22 DTR	√				√	√	√	√	-	-	-	-		
Z 12 XE	√				√	√	√	√	-	-	-	-		
Z 14 XE	√				√	√	√	√	-	-	-	-		
Z 14 XEP	√				√	√	√	√	√	-	-	-		
Z 16 SE	√				√	√	√	√	-	-	-	-		
Z 16 XE	√				√	√	√	√	-	-	-	-		
Z 16 XEP	√				√	√	√	√	-	-	-	-		
Z 16 YNG	√				√	√	√	√	-	-	-	-		

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G		Z 17 DTL	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 18 XEL	√	√	√	√	√	-	-	-	-
			Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
									Software			V6.1
FCAR F3 Diagnostic List												
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	Y 13 DTH	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 14 XEL	√	√	√	-	-	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 XE1	√	√	√	-	-	-	-	-	-
			Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 16 XER	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	√	√	-	-
			Z 17 DTJ	√	√	√	-	-	-	-	-	-
			Z 17 DTL	√	√	√	√	√	√	√	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
			Z 18 XE	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Astra-H		Z 18 XER	√	√	√	√	√	-	√	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-		
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LEL	√	√	√	-	-	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			SLM (Shift Lever Module)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	√	-	√	-	-	
			PEPS (Open&Start)	√	√	√	√	√	√	-	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Anti Theft Warning System	REC (Rear Electrical Centre)	EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	-	-	-	-
				ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
				SAC (Automatic Climate Control)	√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				ABS/TC/ESP ECU (Electronic Control Unit)	√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 17-4		√	√	√	√	-	-	-	-	-
			AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	-	-	-	-	-	-
			MTA (Easytronic Magneti Marelli)		√	√	√	-	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-
			Y 13 DT		√	√	√	√	√	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-C	Engine	Y 17 DT	√	√	√	√	-	-	√	-	-
			Y 17 DTL	√	√	√	√	√	-	-	-	-
			Z 10 XEP	√	√	√	√	√	-	-	-	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DT	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	-	-	-	-
			Z 14 XE	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 YNG	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-
			DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-

 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Corsa-D	Engine	Z 10 XEP	√	√	√	-	-	-	-	-	-
			Z 12 XEP	√	√	√	√	√	√	√	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	√	√	√	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 LER	√	√	√	-	-	-	-	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-
			Anti Theft Warning System	√	√	√	√	√	-	-	-	-
			BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			Exterior Lighting	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	√	√	√	√	-	-	-	-	-
			IPC (Instrument)	√	√	√	√	√	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Interior Lighting	√	√	√	√	-	-	-	-	-
			PAS (Park Pilot)	√	√	√	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	√	-	-	-	-	-
			TIM (Trailer Interface Module)	√	√	√	-	-	-	-	-	-
		Wipers/Washer	√	√	√	√	-	-	-	-	-	
			Chassis	ABS/ESP	√	√	√	√	√	-	-	-

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Chassis	Electronic Power Steering	√	√	√	√	√	√	√	-	-
		Transmission	AF 13-4	√	√	√	√	√	-	-	-	-
			MTA (Easytronic)	√	√	√	-	-	-	-	-	-
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Meriva	Engine	Y 13 DT	√	√	√	√	√	-	-	-	-
			Y 17 DT	√	√	√	√	√	-	-	-	-
			Z 13 DTJ	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 16 LET	√	√	√	-	-	-	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 16 XEP	√	√	√	√	√	-	-	-	-
			Z 17 DT	√	√	√	-	-	-	-	-	-
			Z 17 DTH	√	√	√	√	√	-	-	-	-
			Z 17 DTR	√	√	√	-	-	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-
			Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-

爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
2007		Chassis	Instrument	√	√	√	√	√	-	-	-	-	
			ABS8/ESP8	√	√	√	√	√	-	√	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-	
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-	
		Tigra-B	Engine	Z 13 DT	√	√	√	√	√	-	-	-	-
				Z 14 XEP	√	√	√	√	√	√	-	-	-
	Z 18 XE			√	√	√	√	√	√	-	-	-	
	Airbag			√	√	√	√	-	-	-	-	-	
	Body		Body Control Module	√	√	√	√	√	-	√	-	-	
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
			ABS8/ESP8	√	√	√	√	√	-	√	-	-	
	Chassis		Electronic Power Steering	√	√	√	√	-	-	-	-	-	
			Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
			Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
	EHU (Entertainment Head Unit)			√	√	√	√	√	-	-	-	-	-
				Z 16 XE1	√	√	√	-	-	-	-	-	-
				Z 16 XEP	√	√	√	√	√	√	√	-	-
		Z 16 YNG		√	√	√	-	-	-	-	-	-	
		Z 18 XER		√	√	√	√	√	-	√	-	-	

FCAR 爱夫卡									Automak er			Opel	
FCAR F3 Diagnostic List									Softwar e			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others	
	Zafira-B	Engine	Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	-	-	-	-	-	
			PEPS (Open&Start)	√	√	√	√	-	√	√	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			SDM (Airbag)	√	√	√	√	-	-	√	-	-	
			SLM (Shift Lever Module)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-
			EC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-
			IPC (Instrument)		√	√	√	√	√	-	-	-	-
			CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	√	√	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			SAC (Automatic Climate Control)		√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-				
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	√	√	-	-	-	-
			MTA (Easytronic)		√	√	√	√	√	-	-	-	-
		Infotainment System	EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-
			DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-
			Engine Cooling		√	√	√	√	-	-	-	-	-
			Y 20 DTH		√	√	√	√	√	-	-	-	-
			Y 22 DTR		√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Engine	Z 16 XE	√	√	√	√	√	-	-	-	-	
			Z 16 XEP	√	√	√	-	-	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	√	-	
			Z 18 XER	√	√	√	√	√	√	-	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	-	-	-	
			Z 20 NET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	√	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
			Z 28 NEH	√	√	√	-	-	-	-	-	-	
			Z 28 NEL	√	√	√	√	-	-	√	-	-	
			Z 28 NET	√	√	√	-	-	-	-	-	-	
			Z 30 DT	√	√	√	-	-	-	-	-	-	
			Z 32 SE	√	√	√	√	-	-	-	-	-	
			AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			Additional Heating	ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-
				PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
				REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			IPC (Instrument)	√	√	√	√	√	-	-	-	-	
			Central Door Lock	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-	

										Automak er			Opel
FCAR F3 Diagnostic List										Softwar e			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Vectra-C / Signum	Body	DSM (Driver Seat Module)		√	√	√	√	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-
			Electric Adjustable Mirrors	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			Electrical Horn	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Electronic Seat Memory/Seat Heating	REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			Exterior Lighting	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobliser	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	IPC (Instrument)	√	√	√	√	√	-	-	-	-
				SDM (Airbag)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	-	-	-	-	-
			PDM (Passenger Door Module)		√	√	√	√	-	-	-	-	-
			Power Window Lift	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			REC (Rear Electrical Centre)		√	√	√	√	-	-	-	-	-
			SAC (Automatic Climate Control)		√	√	√	-	-	-	-	-	-
			SDM (Airbag; Sensing&Diagnostic Module)		√	√	√	√	-	-	-	-	-

爱夫卡									Automaker			Opel			
FCAR F3 Diagnostic List									Software			V6.1			
Menu			Function												
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others			
			SLM (Shift Lever Module)		√	√	√	√	-	-	-	-	-		
			SRM (Sun Roof Module)		√	√	√	√	-	-	-	-	-		
			Turn Indication	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-	-	
			UEC (Underhood Electrical Centre)		√	√	√	√	-	-	-	-	-	-	
			Wipers/Washer	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-	-	
		Chassis	ABS/TC/ESP		√	√	√	√	√	-	-	-	-	-	
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-	-	
			EHPS (Electrohydraulic Power Steering)		√	√	√	√	-	-	-	-	-	-	
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-	-	
			Electronic Cruise Control	Engine	√	√	√	√	-	-	-	-	-	-	
			AF 23-5/33-5/40-6		√	√	√	√	√	-	-	-	-	-	
			CVTronic		√	√	√	-	-	-	-	-	-	-	
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-	-	
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-	-	
			EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-	-	
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-	-	
		Vivaro	Engine	F9Q 760/762 (1.9l)		√	√	√	√	√	-	-	-	-	
			Body	Add On Heater		√	√	√	-	-	-	-	-	-	-
				Airbag		√	√	√	√	-	-	-	-	-	-
				Body Control Module		√	√	√	√	√	-	-	-	-	-
				Park Pilot		√	√	√	-	-	-	-	-	-	-
			Chassis	ABS/ESP		√	√	√	√	√	√	√	-	-	
			Transmission	MTA (Tecshift)		√	√	√	-	-	-	-	-	-	

爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
		Infotainme nt System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
	Movano	Engine	G9U 750 (2.5l)	√	√	√	-	-	-	-	-	-
			G9U 754 (2.5l)	√	√	√	-	-	-	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	-	-	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	-	-	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-
		Transmissi on	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
	Vauxhall VXR8	Engine	V8 GEN IV	√	√	√	√	√	-	-	-	-
		Transmissi on	Automatic Transmission	√	√	√	√	√	√	√	-	-
		Chassis	EBCM (Electronic Brake Control Module)	√	√	√	√	√	-	-	-	-
			ESC (Electronic Suspension Control)	√	√	√	√	√	-	√	-	-
		Body	Immobiliser	√	√	√	√	-	√	√	-	-
			BCM (Body Control Module)	√	√	√	√	√	√	√	-	-
			IPC (Instrument Panel Cluster)	√	√	√	√	√	-	-	-	-
			SDM (Sensing and Diagnostic Module)	√	√	√	√	-	-	√	-	-
			HVAC (Heating Ventilation and Cooling)	√	√	√	√	√	-	√	-	-
			RFA (Remote Function Actuator)	√	√	√	√	-	√	√	-	-
			MSM (Memory Seat and Mirrors)	√	√	√	√	√	-	√	-	-
			Park Assist	√	√	√	√	√	-	-	-	-
			AHL (Automatic Headlamp Levelling)	√	√	√	√	√	√	√	-	-
			Audio System	√	√	√	√	√	-	√	-	-

爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel	
									Softwar e			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others	
		Infotainme nt System	Driver Information Display	√	√	√	√	-	-	-	-	-	
			RSE (Rear Seat Entertainment)	√	√	√	√	√	-	-	-	-	
			Telematics	√	√	√	√	√	-	√	-	-	
	Speedster /VX220	Engine	Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
		Body	Airbag	-	√	√	-	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	-	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-	-
		Chassis	ABS 430	√	√	√	√	√	-	-	-	-	-
	Captiva (Long Body)	Engine	2.0 L (Diesel)	√	√	√	-	-	-	-	-	-	-
			Z 24 XE	√	√	√	-	-	-	-	-	-	-
			Z 32 SE	√	√	√	√	√	-	-	-	-	-
		Body	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	-	-	-	-	-	-	-
			IPC (Instrument)	√	√	√	-	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-	-
			RFA (Multipurpose Receiver Module)	√	√	√	-	-	-	-	-	-	-
			SDM (Airbag)	√	√	√	-	-	-	-	-	-	-
			XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	√	√	√	√	√	-	-	-	-	-
		Transmissi on	Automatic Transmission	√	√	√	-	-	-	-	-	-	-
			TCCM (Transfer Case Control Module)	√	√	√	-	-	-	-	-	-	-
		Engine	2.0 L (Diesel)	√	√	√	-	-	-	-	-	-	-
			Z 24 XE	√	√	√	-	-	-	-	-	-	-
			Z 32 SE	√	√	√	-	-	-	-	-	-	-
			AHL (Automatic Headlamp Levelling)	√	√	√	-	-	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List										Automaker			Opel	
										Software			V6.1	
Menu			Function											
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
Antara, Captiva (Short Body)	Body	Body	Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
				XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-	
			BCM (Body Control Module)		√	√	√	-	-	-	-	-	-	
			Central Door Lock	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			ECC (Electronic Climate Control)		√	√	√	-	-	-	-	-	-	
			Exterior Lighting/Turn Indicator	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			HVAC (Heating Ventilation and Cooling)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			IPC (Instrument)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			Immobiliser	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			PAS (Park Pilot)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			RFA (Multipurpose Receiver)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			SLM (Shift Lever Module)	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
				XBCM (Auxiliary Body Control Module)	√	√	√	-	-	-	-	-	-	
			Wipers/Washer	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			XBCM (Auxiliary Body Control Module)		√	√	√	-	-	-	-	-	-	
			Chassis	ABS/TC/ESP (Vehicle Dynamic System)		√	√	√	-	-	-	-	-	-
			Transmissi	Automatic Transmission		√	√	√	-	-	-	-	-	-

 爱夫卡									Automaker			Opel		
FCAR F3 Diagnostic List									Software			V6.1		
Menu			Function											
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others		
		on	TCCM (Transfer Case Control Module)	√	√	√	-	-	-	-	-	-		
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-		
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-		
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-		
	Agila-B	Engine	Z 10 XEP	√	√	√	√	√	-	-	-	-		
			Z 12 XE	√	√	√	√	√	-	-	-	-		
			Z 12 XEP	√	√	√	√	√	-	-	-	-		
			Z 13 DT	√	√	√	√	√	-	-	-	-		
		Body	Airbag	√	√	√	√	-	-	-	-	-		
			Immobiliser	√	√	√	√	-	-	-	-	-		
			Instrument	√	√	√	√	√	-	-	-	-		
		Chassis	ABS	√	√	√	√	√	-	√	-	-		
			Electronic Power Steering	√	√	√	√	-	-	-	-	-		
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-		
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-		
				Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
					Y 17 DT	√	√	√	√	-	-	√	-	-
					Y 20 DTH	√	√	√	√	√	-	√	-	-
Y 22 DTR	√				√	√	√	√	-	-	-	-		
Z 12 XE	√				√	√	√	√	-	-	-	-		
Z 14 XE	√				√	√	√	√	-	-	-	-		
Z 14 XEP	√				√	√	√	√	√	-	-	-		
Z 16 SE	√				√	√	√	√	-	-	-	-		
Z 16 XE	√				√	√	√	√	-	-	-	-		
Z 16 XEP	√				√	√	√	√	-	-	-	-		
Z 16 YNG	√				√	√	√	√	-	-	-	-		

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G		Z 17 DTL	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 18 XEL	√	√	√	√	√	-	-	-	-
			Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
									Software			V6.1
FCAR F3 Diagnostic List												
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	Z 12 XEP	√	√	√	√	√	-	-	-	-
			Z 13 DTH	√	√	√	√	√	-	-	-	-
			Z 14 XEL	√	√	√	-	-	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	√	-	-
			Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 17 DTH	√	√	√	√	√	√	√	-	-
			Z 17 DTL	√	√	√	√	√	√	√	-	-
			Z 18 XE	√	√	√	-	-	-	-	-	-
			Z 18 XER	√	√	√	√	√	-	√	-	-
			Z 19 DT	√	√	√	√	-	-	-	-	-
			Z 19 DTH	√	√	√	√	√	-	√	-	-
			Z 20 LEH	√	√	√	√	√	-	-	-	-
			Z 20 LEL	√	√	√	-	-	-	-	-	-
			Z 20 LER	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Astra-H	Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-	
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-	
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-	
			SLM (Shift Lever Module)	√	√	√	-	-	-	-	-	-	
			SDM (Airbag)	√	√	√	√	√	-	-	-	-	
			PAS (Park Pilot)	√	√	√	√	√	-	√	-	-	
			PEPS (Open&Start)	√	√	√	√	√	√	-	-	-	
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	
			UEC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-	
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	√	-	-	-	-
				ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
				SAC (Automatic Climate Control)	√	√	√	√	√	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 17-4		√	√	√	√	-	-	-	-	-
			AF 40-6		√	√	√	-	-	-	-	-	-
			MTA (Easytronic Magneti Marelli)		√	√	√	-	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-
	Engine		Y 13 DT		√	√	√	√	√	-	-	-	-
			Y 17 DT		√	√	√	√	-	-	√	-	-
			Y 17 DTL		√	√	√	√	√	-	-	-	-
			Z 10 XEP		√	√	√	√	√	-	-	-	-
			Z 12 XE		√	√	√	√	√	-	-	-	-
			Z 12 XEP		√	√	√	√	√	-	-	-	-
			Z 13 DT		√	√	√	√	√	-	-	-	-
			Z 13 DTJ		√	√	√	√	√	-	-	-	-
			Z 14 XE		√	√	√	√	√	-	-	-	-

 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Corsa-C		Z 14 XEP	√	√	√	√	√	√	-	-	-	
			Z 16 SE	√	√	√	√	√	-	-	-	-	
			Z 16 YNG	√	√	√	√	√	-	-	-	-	
			Z 17 DTH	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
		Body	Add On Heater	√	√	√	-	-	-	-	-	-	
			Airbag	√	√	√	√	-	-	-	-	-	
			Body Control Module	√	√	√	√	√	-	√	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			ABS8/ESP8	√	√	√	√	√	-	√	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
			DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-	
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-	
				Y 13 DT	√	√	√	√	√	-	-	-	-
				Y 17 DT	√	√	√	√	√	-	-	-	-
				Z 13 DTJ	√	√	√	√	√	-	-	-	-
				Z 14 XEP	√	√	√	√	√	√	-	-	-
				Z 16 LET	√	√	√	-	-	-	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Meriva	Engine	Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 16 XEP	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	AFL (Adaptive Forward Lighting)	√	√	√	-	-	-	-	-	-
			Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
		Engine	Z 13 DT	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
2006	Tigra-B	Body	Body Control Module	√	√	√	√	√	-	√	-	-
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
			transmission MTA (Easytronic)	√	√	√	√	√	-	-	-	-
			Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-
	EHU (Entertainment Head Unit)	√		√	√	√	√	-	-	-	-	
		Engine	Z 16 XEP	√	√	√	√	√	√	√	-	-
			Z 16 YNG	√	√	√	-	-	-	-	-	-
			Z 18 XER	√	√	√	√	√	-	√	-	-
			Z 19 DT	√	√	√	√	-	-	-	-	-
			Z 19 DTH	√	√	√	√	√	-	√	-	-
			Z 20 LEH	√	√	√	√	√	-	-	-	-
			Z 20 LER	√	√	√	-	-	-	-	-	-
			Z 22 YH	√	√	√	√	√	-	-	-	-
			AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			EHS (Electrical Heater System)	√	√	√	-	-	-	-	-	-
			IPC ECU (Instrument Control Unit)	√	√	√	√	√	-	-	-	-
			PAS (Park Pilot)	√	√	√	√	-	-	-	-	-
			PEPS (Open&Start)	√	√	√	√	-	√	√	-	-
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			SDM (Airbag)	√	√	√	√	-	-	√	-	-
			SLM (Shift Lever Module)	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡										Automaker			Opel		
FCAR F3 Diagnostic List										Software			V6.1		
Menu			Function												
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others		
	Zafira-B	Body	UEC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-		
			Immobiliser	REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	
				EC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-	
				IPC (Instrument)		√	√	√	√	√	-	-	-	-	
				CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-	
			Instrument	REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	
				REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	
			Anti Theft Warning System	EC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-	
				IPC (Instrument)		√	√	√	√	√	-	-	-	-	
				CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-	
				PEPS (Open&Start)		√	√	√	√	-	√	√	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	
			Central Door Lock	REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	
			Wipers/Washer	REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	
		Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	-	
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-	-	
		SAC (Automatic Climate Control)		√	√	√	√	√	-	-	-	-	-	-	
		Chassis		ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)		√	√	√	√	-				
				ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-	-
				CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-	-
				TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-	-
				TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			EHPS (Electrohydraulic Power Steering) KWP	√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN	√	√	√	√	-	-	-	-	-
		Transmission	AF 22-4	√	√	√	-	-	-	-	-	-
			AF 40-6	√	√	√	√	√	-	-	-	-
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment System	EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
			DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
		Engine	Engine Cooling	√	√	√	√	-	-	-	-	-
	Y 20 DTH		√	√	√	√	√	-	-	-	-	
	Y 22 DTR		√	√	√	√	√	-	-	-	-	
	Z 16 XE		√	√	√	√	√	-	-	-	-	
	Z 16 XEP		√	√	√	-	-	-	-	-	-	
	Z 18 XE		√	√	√	√	√	√	-	√	-	
	Z 18 XER		√	√	√	√	√	√	-	-	-	
	Z 19 DT		√	√	√	√	-	-	-	-	-	
	Z 19 DTH		√	√	√	√	√	-	-	-	-	
	Z 20 NET		√	√	√	√	√	-	-	-	-	
	Z 22 SE		√	√	√	√	√	√	√	-	-	
	Z 22 YH		√	√	√	√	√	-	-	-	-	
	Z 28 NEL		√	√	√	√	-	-	√	-	-	
	Z 28 NET		√	√	√	-	-	-	-	-	-	
	Z 30 DT		√	√	√	-	-	-	-	-	-	
	Z 32 SE		√	√	√	√	-	-	-	-	-	
		AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-C / Signum	Body	Additional Heating	ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-
				PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
				REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			BCM (Body Control Module)		√	√	√	-	-	-	-	-	-
			CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-
			IPC (Instrument)		√	√	√	√	√	-	-	-	-
			Central Door Lock	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			DDM (Driver Door Module)		√	√	√	√	-	-	-	-	-
			DSM (Driver Seat Module)		√	√	√	√	-	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-
			Electric Adjustable Mirrors	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			Electrical Horn	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Electronic Seat Memory/Seat Heating	REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			Exterior Lighting	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Immobiliser	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	IPC (Instrument)	√	√	√	√	√	-	-	-	-
				SDM (Airbag)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	-	-	-	-	-
			PDM (Passenger Door Module)		√	√	√	√	-	-	-	-	-
			Power Window Lift	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			REC (Rear Electrical Centre)		√	√	√	√	-	-	-	-	-
			SAC (Automatic Climate Control)		√	√	√	-	-	-	-	-	-
			SDM (Airbag; Sensing&Diagnostic Module)		√	√	√	√	-	-	-	-	-
			SLM (Shift Lever Module)		√	√	√	√	-	-	-	-	-
			SRM (Sun Roof Module)		√	√	√	√	-	-	-	-	-
			Turn Indication	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			UEC (Underhood Electrical Centre)		√	√	√	√	-	-	-	-	-
			Wipers/Washer	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
		Chassis	ABS/TC/ESP		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering)		√	√	√	√	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			Electronic Cruise Control	Engine	√	√	√	√	-	-	-	-	-
	Transmission		AF 23-5/33-5/40-6		√	√	√	√	√	-	-	-	-
			CVTronic		√	√	√	-	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-
			DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	DIS (Info Display TID,BID,GID,CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)	√	√	√	-	-	-	-	-	-
	Vivaro	Engine	F4R 720 (2.0l)	√	√	√	-	-	-	-	-	-
			F9Q 760/762 (1.9l)	√	√	√	√	√	-	-	-	-
			G9U 730 (2.5l)	√	√	√	-	-	-	-	-	-
			G9U 730 MTA (2.5l)	√	√	√	-	-	-	-	-	-
			Add On Heater	√	√	√	-	-	-	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-
			Chassis	ABS/ESP	√	√	√	√	√	√	√	-
		Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDC 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
	Telematic Unit		√	√	√	-	-	-	-	-	-	
	Triple Info Display	√	√	√	√	-	-	-	-	-		
			F9Q 774 (1.9l)	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
									Software			V6.1	
FCAR F3 Diagnostic List													
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Movano	Engine	G9T 750 (2.2l)	√	√	√	-	-	-	-	-	-	
			G9U 750 (2.5l)	√	√	√	-	-	-	-	-	-	
			G9U 750 MTA (2.5l)	√	√	√	-	-	-	-	-	-	
			G9U 754 (2.5l)	√	√	√	-	-	-	-	-	-	
			ZD3 200/202 (3.0l)	√	√	√	-	-	-	-	-	-	
		Body	Airbag	√	√	√	√	-	-	-	-	-	-
			Body Control Module	√	√	√	-	-	-	-	-	-	-
			CAN Interface Module	√	√	√	-	-	-	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	√	√	√	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-	-
		Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-	-
	Vauxhall VXR8	Engine	V8 GEN III	√	√	√	-	√	-	-	-	-	-
			V8 GEN IV	√	√	√	√	√	-	-	-	-	-
		Body	Audio System	√	√	√	√	√	-	-	-	-	-
			Auxiliary Gauges	√	-	√	√	-	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-	-
			Occupant Climate Control	√	√	√	√	√	-	-	-	-	-
			Powertrain Interface Module	√	√	√	√	√	-	-	-	-	-
			SRS	√	√	√	√	-	-	-	-	-	-
			ABS / ETC	√	√	√	√	-	-	-	-	-	-
		Chassis	ABS/TC/ESP 8.0	√	√	√	√	√	-	-	-	-	-
			GEN III ABS / ETC	-	√	√	-	-	-	-	-	-	-
			Automatic Transmission	√	√	√	√	√	√	-	-	-	-

 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Transmission	GEN III Automatic Transmission	√	√	√	-	√	-	-	-	-	
	Speedster /VX220	Engine	Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
		Body	Airbag	-	√	√	-	-	-	-	-	-	
			Anti Theft Warning	√	√	√	-	-	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
		Chassis	ABS 430	√	√	√	√	√	-	-	-	-	
	Agila-B	Engine	Z 10 XEP	√	√	√	√	√	-	-	-	-	
			Z 12 XE	√	√	√	√	√	-	-	-	-	
			Z 12 XEP	√	√	√	√	√	-	-	-	-	
			Z 13 DT	√	√	√	√	√	-	-	-	-	
			Airbag	√	√	√	√	-	-	-	-	-	
		Body	Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
			Chassis	ABS	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Infotainment System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-	
	EHU (Entertainment Head Unit)		√	√	√	-	-	-	-	-	-		
				C 16 SEL	√	√	√	√	√	-	√	√	-
				Y 17 DT	√	√	√	√	-	-	√	-	-
				Y 20 DTH	√	√	√	√	√	-	√	-	-
				Y 22 DTR	√	√	√	√	√	-	-	-	-
Z 12 XE				√	√	√	√	√	-	-	-	-	
Z 14 XE				√	√	√	√	√	-	-	-	-	
Z 14 XEP				√	√	√	√	√	√	-	-	-	
	Z 16 SE	√	√	√	√	√	-	-	-	-			

 爱夫卡									Automak er			Opel	
FCAR F3 Diagnostic List									Softwar e			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others	
	Astra-G	Engine	Z 16 XE	√	√	√	√	√	-	-	-	-	
			Z 16 XEP	√	√	√	√	√	-	-	-	-	
			Z 16 YNG	√	√	√	√	√	-	-	-	-	
			Z 17 DTL	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
			Z 18 XEL	√	√	√	√	√	-	-	-	-	
			Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
		Body	Add On Heater	√	√	√	-	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-	-
		Transmissi on	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-	-

爱夫卡										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Infotainment System	Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Multi Info Display	√	√	√	√	-	-	-	-	-	
			Radio 420	√	√	√	-	-	-	-	-	-	
			Radio 435	√	√	√	-	-	-	-	-	-	
			Radio 520	√	√	√	-	-	-	-	-	-	
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-	
			Radio CAR 300	√	√	√	√	-	-	-	-	-	
			Radio CAR 400	√	√	√	√	√	-	-	-	-	
			Radio CCR 600	√	√	√	√	√	-	-	-	-	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
		Engine	Z 13 DTH	√	√	√	√	√	-	-	-	-	
			Z 14 XEP	√	√	√	√	√	√	√	-	-	
			Z 16 XEP	√	√	√	√	√	√	√	-	-	
			Z 17 DTH	√	√	√	√	√	√	√	-	-	
			Z 17 DTL	√	√	√	√	√	√	√	-	-	
			Z 18 XE	√	√	√	-	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LEH	√	√	√	√	√	-	-	-	-	
			Z 20 LEL	√	√	√	-	-	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-H	Body	Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	-	-	-	-
			CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			IPC ECU (Instrument Control Unit)		√	√	√	√	√	-	-	-	-
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	√	-	√	-	-
			REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-
			SDM (Airbag)		√	√	√	√	√	-	-	-	-
			UEC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			TPMS (Tyre Pressure Monitoring System)	√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)	√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP	√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN	√	√	√	√	-	-	-	-	-
		Transmission	AF 17-4	√	√	√	√	-	-	-	-	-
			MTA (Easytronic)	√	√	√	-	-	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	√	√	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
		Corsa-C	Engine	Y 13 DT	√	√	√	√	√	-	-	-
	Y 17 DT			√	√	√	√	-	-	√	-	-
	Y 17 DTL			√	√	√	√	√	-	-	-	-
	Z 10 XEP			√	√	√	√	√	-	-	-	-
	Z 12 XE			√	√	√	√	√	-	-	-	-
	Z 12 XEP			√	√	√	√	√	-	-	-	-
	Z 13 DT			√	√	√	√	√	-	-	-	-
	Z 14 XE			√	√	√	√	√	-	-	-	-
	Z 14 XEP			√	√	√	√	√	√	-	-	-
	Z 16 SE			√	√	√	√	√	-	-	-	-
	Z 16 YNG			√	√	√	√	√	-	-	-	-
	Z 17 DTH			√	√	√	√	√	-	-	-	-
	Z 18 XE			√	√	√	√	√	√	-	-	-
	Body		Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
									Software			V6.1	
FCAR F3 Diagnostic List													
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
			Immobiliser	√	√	√	√	-	-	-	-		
			Instrument	√	√	√	√	√	-	-	-		
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			ABS8/ESP8	√	√	√	√	√	-	√	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
		Infotainment System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
			DIS (Info Display TID,BID,GID,CID)	√	√	√	-	-	-	-	-	-	
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-	
		Meriva	Engine	Y 13 DT	√	√	√	√	√	-	-	-	-
				Y 17 DT	√	√	√	√	√	-	-	-	-
				Z 14 XEP	√	√	√	√	√	√	-	-	-
	Z 16 SE			√	√	√	√	√	-	-	-	-	
	Z 16 XE			√	√	√	√	√	-	-	-	-	
	Z 17 DTH			√	√	√	√	√	-	-	-	-	
	Z 18 XE			√	√	√	√	√	√	-	-	-	
	Body		Add On Heater	√	√	√	-	-	-	-	-	-	
			Airbag	√	√	√	√	-	-	-	-	-	
			Body Control Module	√	√	√	√	√	-	√	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
		Immobiliser	√	√	√	√	-	-	-	-	-		
		Instrument	√	√	√	√	√	-	-	-	-		
			ABS8/ESP8	√	√	√	√	√	-	√	-	-	

FCAR 爱夫卡									Automak er			Opel
FCAR F3 Diagnostic List									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
		Chassis	Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmissi on	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainme nt System	DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	-	-	-	-	-	-
	Tigra-B	Engine	Z 13 DT	√	√	√	√	√	-	-	-	-
			Z 14 XEP	√	√	√	√	√	√	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			Electrohydraulic Hardtop	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		ransmissio	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainme nt System	DIS (Info Display TID, BID, GID, CID)	√	√	√	-	-	-	-	-	-
			EHU (Entertainment Head Unit)	√	√	√	√	√	-	-	-	-
		Engine	Y 20 DTH	√	√	√	√	-	-	-	-	-
			Y 22 DTR	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 16 YNG	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
2005	Zafira	Body	Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device(Left)	√	√	√	√	√	-	√	-	-
			Headlamp Levelling Device(Right)	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
		Engine	Z 16 XEP	√	√	√	√	√	√	√	-	-	
			Z 18 XER	√	√	√	√	√	-	√	-	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	√	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
			Body	AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-
		CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-	
		EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-	
		IPC ECU (Instrument Control Unit)		√	√	√	√	√	-	-	-	-	
		PAS (Park Pilot)		√	√	√	√	-	-	-	-	-	
		PEPS (Open&Start)		√	√	√	√	-	√	√	-	-	
		REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-	
		SDM (Airbag)		√	√	√	√	-	-	√	-	-	
		SLM (Shift Lever Module)		√	√	√	√	√	-	-	-	-	
		UEC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-	
		Immobiliser		REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
		Instrument		CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-	

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Zafira-B		Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	√	√	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-				
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 22-4		√	√	√	-	-	-	-	-	-
			AF 40-6		√	√	√	√	√	-	-	-	-
		Infotainment System	EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
			UHP (Mobile Phone Portal)		√	√	√	-	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			DAB (Digital Audio Broadcast)	√	√	√	-	-	-	-	-	-	
		Engine	Engine Cooling	√	√	√	√	-	-	-	-	-	
			Y 20 DTH	√	√	√	√	√	-	-	-	-	
			Y 22 DTR	√	√	√	√	√	-	-	-	-	
			Z 16 XE	√	√	√	√	√	-	-	-	-	
			Y 30 DT	√	√	√	-	-	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	√	-	
			Z 19 DT	√	√	√	√	-	-	-	-	-	
			Z 19 DTH	√	√	√	√	√	-	-	-	-	
			Z 20 NET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	√	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
			Z 32 SE	√	√	√	√	-	-	-	-	-	
				AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-
		Additional Heating		ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
		Anti Theft Warning System		BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-
				PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
				REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
		BCM (Body Control Module)		√	√	√	-	-	-	-	-	-	
		CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-	
		IPC (Instrument)		√	√	√	√	√	-	-	-	-	
		Central Door Lock		PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
		DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-	-	
	DSM (Driver Seat Module)	√	√	√	√	-	-	-	-	-	-		

 爱夫卡									Automaker				Opel
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-C / Signum	Body	ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			Electric Adjustable Mirrors	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			Electrical Horn	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Electronic Seat Memory/Seat Heating	REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			Exterior Lighting	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobiliser	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	IPC (Instrument)	√	√	√	√	√	-	-	-	-
				SDM (Airbag)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	-	-	-	-	-
			PDM (Passenger Door Module)		√	√	√	√	-	-	-	-	-
			Power Window Lifter	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			REC (Rear Electrical Centre)		√	√	√	√	-	-	-	-	-
			SDM (Airbag; Sensing&Diagnostic Module)		√	√	√	√	-	-	-	-	-
			SLM (Shift Lever Module)		√	√	√	√	-	-	-	-	-
			SRM (Sun Roof Module)		√	√	√	√	-	-	-	-	-
			Turn Indication		EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel			
FCAR F3 Diagnostic List									Software			V6.1			
Menu			Function												
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others			
			UEC (Underhood Electrical Centre)		√	√	√	√	-	-	-	-	-		
			Wipers/Washer EC (Underhood Electrical Centre)		√	√	√	√	-	-	-	-	-		
		Chassis	ABS/TC/ESP		√	√	√	√	√	-	-	-	-	-	
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-	-	
			EHPS (Electrohydraulic Power Steering)		√	√	√	√	-	-	-	-	-	-	
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-	-	
			Electronic Cruise Control	Engine	√	√	√	√	-	-	-	-	-	-	
			Transmission	AF 23-5/33-5/40-6		√	√	√	√	√	-	-	-	-	-
		CVTronic		√	√	√	-	-	-	-	-	-	-		
		Infotainment System	DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-	-	
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-	-	
			EHU (Entertainment Head Unit)		√	√	√	√	√	-	-	-	-	-	
		Vivaro	Engine	F4R 720 (2.0l)		√	√	√	-	-	-	-	-	-	-
				F9Q 760/762 (1.9l)		√	√	√	√	√	-	-	-	-	-
				G9U 730 (2.5l)		√	√	√	-	-	-	-	-	-	-
	G9U 730 MTA (2.5l)			√	√	√	-	-	-	-	-	-	-		
	Body		Add On Heater		√	√	√	-	-	-	-	-	-	-	
			Airbag		√	√	√	√	-	-	-	-	-	-	
			Body Control Module		√	√	√	√	√	-	-	-	-	-	
	Chassis		ABS/ESP		√	√	√	√	√	√	√	-	-	-	
	Transmission		MTA (Tecshift)		√	√	√	-	-	-	-	-	-	-	
			CD-Changer		√	√	√	-	-	-	-	-	-	-	
		Global Positioning System GPS		√	√	√	-	-	-	-	-	-	-		
		Graphical/Colour Info Display		√	√	√	-	-	-	-	-	-	-		

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Infotainment System	Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Radio CAR 2004	√	√	√	-	-	-	-	-	-	
			Radio CART 2007	√	√	√	-	-	-	-	-	-	
			Radio CCR 2006	√	√	√	√	-	-	-	-	-	
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-	
			Radio CDR 2005	√	√	√	√	-	-	-	-	-	
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
	Movano	Engine	F9Q 774 (1.9l)	√	√	√	-	-	-	-	-	-	
			G9T 750 (2.2l)	√	√	√	-	-	-	-	-	-	
			G9U 750 (2.5l)	√	√	√	-	-	-	-	-	-	
			G9U 750 MTA (2.5l)	√	√	√	-	-	-	-	-	-	
			G9U 754 (2.5l)	√	√	√	-	-	-	-	-	-	
			ZD3 200/202 (3.0l)	√	√	√	-	-	-	-	-	-	
			Airbag	√	√	√	√	-	-	-	-	-	
		Body	Body Control Module	√	√	√	-	-	-	-	-	-	
			Park Pilot	√	√	√	-	-	-	-	-	-	
			ABS/ESP	√	√	√	√	√	√	√	-	-	
		Chassis	Pneumatic Suspension	√	√	√	-	-	-	-	-	-	
			Transmission	MTA (Tecshift)	√	√	√	-	-	-	-	-	-
			Engine	V8 GEN III	√	√	√	-	√	-	-	-	-
				V8 GEN IV	√	√	√	√	√	-	-	-	-
				Audio System	√	√	√	√	√	-	-	-	-
				Auxiliary Gauges	√	-	√	√	-	-	-	-	-

 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Vauxhall VXR8	Body	Body Control Module	√	√	√	√	√	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
			Occupant Climate Control	√	√	√	√	√	-	-	-	-	
			Powertrain Interface Module	√	√	√	√	√	-	-	-	-	
			SRS	√	√	√	√	-	-	-	-	-	
		Chassis	ABS / ETC	√	√	√	√	-	-	-	-	-	
			ABS/TC/ESP 8.0	√	√	√	√	√	-	-	-	-	
			GEN III ABS / ETC	-	√	√	-	-	-	-	-	-	
			Transmission	Automatic Transmission	√	√	√	√	√	√	-	-	-
				GEN III Automatic Transmission	√	√	√	-	√	-	-	-	-
	Speedster /VX220	Engine	Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
			Airbag	-	√	√	-	-	-	-	-	-	
		Body	Anti Theft Warning	√	√	√	-	-	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Chassis	ABS 430	√	√	√	√	√	-	-	-	-
Agila-B		Engine	Z 10 XEP	√	√	√	√	√	-	-	-	-	
	Z 12 XE		√	√	√	√	√	-	-	-	-		
	Z 13 DT		√	√	√	√	√	-	-	-	-		
	Airbag		√	√	√	√	-	-	-	-	-		
	Body	Immobiliser	√	√	√	√	-	-	-	-	-		
		Instrument	√	√	√	√	√	-	-	-	-		
		ABS	√	√	√	√	√	-	√	-	-		
	Chassis	Electronic Power Steering	√	√	√	√	-	-	-	-	-		
		Infotainment	Radio CAR 2003	√	√	√	√	-	-	-	-	-	
			Radio CDR 2005	√	√	√	√	-	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Int System	Triple Info Display	√	√	√	√	-	-	-	-	-
	Astra-G	Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
			Y 17 DT	√	√	√	√	-	-	√	-	-
			Y 20 DTH	√	√	√	√	√	-	√	-	-
			Y 22 DTR	√	√	√	√	√	-	-	-	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 14 XE	√	√	√	√	√	-	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 16 XEP	√	√	√	√	√	-	-	-	-
			Z 16 YNG	√	√	√	√	√	-	-	-	-
			Z 17 DTL	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 18 XEL	√	√	√	√	√	-	-	-	-
			Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
			Body	Add On Heater	√	√	√	-	-	-	-	-
		Airbag		-	√	√	-	-	-	-	-	-
		Anti Theft Warning		√	√	√	√	√	-	-	-	-
		Central Door Lock		√	√	√	√	√	-	-	-	-
		Electronic Climate Control		√	√	√	√	√	-	-	-	-
		Engine Cooling Module		√	√	√	√	-	-	-	-	-
		Headlamp Levelling Device		√	√	√	√	√	-	√	-	-
		Immobiliser		√	√	√	√	-	-	-	-	-
		Instrument		√	√	√	√	√	-	-	-	-
		Softtop Controller	√	√	√	√	√	-	-	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			Cruise Control	√	√	√	-	-	-	-	-	-	
			ESP	√	√	√	√	√	-	-	-	-	
			Electronic Power Steering	√	√	√	√	√	-	-	-	-	
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-	
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-	
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-	
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Multi Info Display	√	√	√	√	-	-	-	-	-	
			Radio 420	√	√	√	-	-	-	-	-	-	
			Radio 435	√	√	√	-	-	-	-	-	-	
			Radio 520	√	√	√	-	-	-	-	-	-	
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-	
			Radio CAR 300	√	√	√	√	-	-	-	-	-	
			Radio CAR 400	√	√	√	√	√	-	-	-	-	
			Radio CCR 600	√	√	√	√	√	-	-	-	-	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
		Triple Info Display	√	√	√	√	-	-	-	-	-		
			Z 14 XEP	√	√	√	√	√	√	√	-	-	
			Z 16 XEP	√	√	√	√	√	√	√	√	-	-
			Z 17 DTH	√	√	√	√	√	√	√	√	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
Astra-H		Engine	Z 17 DTL	√	√	√	√	√	√	√	-	-	
			Z 18 XE	√	√	√	-	-	-	-	-	-	
			Z 20 LEL	√	√	√	-	-	-	-	-	-	
			Z 20 LER	√	√	√	-	-	-	-	-	-	
		Body	AHL/AFL (Headlamp Levelling)		√	√	√	-	-	-	-	-	-
			Anti Theft Warning System	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	√	-	-	-	-
				IPC (Instrument)	√	√	√	√	√	-	-	-	-
				CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				PEPS (Open&Start)	√	√	√	√	-	-	-	-	-
			CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-
			Central Door Lock	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			ECC (Electronic Climate Control)		√	√	√	√	√	-	-	-	-
			EHS (Electrical Heater System)		√	√	√	-	-	-	-	-	-
			Exterior Lighting/Turn Indicator	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			IPC ECU (Instrument Control Unit)		√	√	√	√	√	-	-	-	-
			Immobiliser	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Instrument	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			Interior Lighting	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	√	-	√	-	-
			REC (Rear Electrical Centre)		√	√	√	√	√	-	-	-	-
			SDM (Airbag)		√	√	√	√	√	-	-	-	-
			UEC (Underhood Electrical Centre)		√	√	√	√	√	-	-	-	-
			Wipers/Washer	REC (Rear Electrical Centre)	√	√	√	√	√	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Chassis	ABS/TC/ESP (Vehicle Dynamic System)	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			ABS/TC/ESP ECU (Electronic Control Unit)		√	√	√	√	√	-	-	-	-
			CDC (Continuous Damping Control)		√	√	√	-	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			TPMS ECU (Tyre Pressure Monitoring)		√	√	√	-	-	-	-	-	-
			EHPS (Electrohydraulic Power Steering) KWP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering) CAN		√	√	√	√	-	-	-	-	-
		Transmission	AF 17-4		√	√	√	√	-	-	-	-	-
			MTA (Easytronic)		√	√	√	-	-	-	-	-	-
		Infotainment System	DAB (Digital Audio Broadcast)		√	√	√	-	-	-	-	-	-
			DIS (Info Display TID, BID, GID, CID)		√	√	√	√	√	-	-	-	-
		EHU (Entertainment Head Unit)		√	√	√	√	√	√	-	-	-	-
		Engine	Y 17 DT		√	√	√	√	-	-	√	-	-
			Y 17 DTL		√	√	√	√	√	-	-	-	-
			Z 10 XEP		√	√	√	√	√	-	-	-	-
			Z 12 XE		√	√	√	√	√	-	-	-	-
			Z 13 DT		√	√	√	√	√	-	-	-	-
			Z 14 XE		√	√	√	√	√	-	-	-	-
			Z 14 XEP		√	√	√	√	√	√	-	-	-
			Z 16 SE		√	√	√	√	√	-	-	-	-
			Z 17 DTH		√	√	√	√	√	-	-	-	-
			Z 18 XE		√	√	√	√	√	√	-	-	-
			Add On Heater		√	√	√	-	-	-	-	-	-
			Airbag		√	√	√	√	-	-	-	-	-

 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-C	Body	Body Control Module	√	√	√	√	√	-	√	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			ABS8/ESP8	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio 2020	√	√	√	-	-	-	-	-	-
			Radio 2620	√	√	√	-	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Y 20 DTH	√	√	√	√	-	-	-	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
2004	Zafira	Engine	Y 22 DTR	√	√	√	√	√	-	-	-	-	
			Z 16 XE	√	√	√	√	√	-	-	-	-	
			Z 16 YNG	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
			Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
		Body	Airbag	-	√	√	-	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-	
			Central Door Lock	√	√	√	√	√	-	-	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Engine Cooling Module	√	√	√	√	-	-	-	-	-	
			Headlamp Levelling Device(Left)	√	√	√	√	√	-	√	-	-	
			Headlamp Levelling Device(Right)	√	√	√	√	√	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			ESP	√	√	√	√	√	-	-	-	-	
			Electronic Power Steering	√	√	√	√	√	-	-	-	-	
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
			CD-Changer	√	√	√	-	-	-	-	-	-	
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-	
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Multi Info Display	√	√	√	√	-	-	-	-	-	
			Radio 420	√	√	√	-	-	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
	Triple Info Display	√	√	√	√	-	-	-	-	-		
	Meriva	Engine	Y 17 DT	√	√	√	√	√	-	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 17 DTH	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	Engine Cooling	√	√	√	√	-	-	-	-	-
			Y 20 DTH	√	√	√	√	√	-	-	-	-
			Y 22 DTR	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Y 30 DT	√	√	√	-	-	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	√	-
			Z 19 DT	√	√	√	√	-	-	-	-	-
			Z 19 DTH	√	√	√	√	√	-	-	-	-
			Z 20 NET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	√	-	-
			Z 22 YH	√	√	√	√	√	-	-	-	-
			Z 32 SE	√	√	√	√	-	-	-	-	-
				AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-
			ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-

 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
Vectra-C / Signum		Body	Additional Heating	BCM (Body Control Module)	√	√	√	-	-	-	-	-
			Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-
				DDM (Driver Door Module)	√	√	√	√	-	-	-	-
				PDM (Passenger Door Module)	√	√	√	√	-	-	-	-
				REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	-	-	-	-	-
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	
			IPC (Instrument)	√	√	√	√	√	-	-	-	
			Central Door Lock	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-
			DDM (Driver Door Module)	√	√	√	√	-	-	-	-	
			DSM (Driver Seat Module)	√	√	√	√	-	-	-	-	
			ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	
			Electric Adjustable Mirrors	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-
			Electrical Horn	CIM (Steering Column Module)	√	√	√	√	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-
			Electronic Seat Memory/Seat Heating	REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-
			Exterior Lighting	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-
			Heating, Ventilation and Air Cond.	BCM (Body Control Module)	√	√	√	-	-	-	-	-
Immobiliser	CIM (Steering Column Module)	√	√	√	√	-	-	-	-			
	IPC (Instrument)	√	√	√	√	√	-	-	-			

FCAR 爱夫卡										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Instrument	SDM (Airbag)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	-	-	-	-	-
			PDM (Passenger Door Module)		√	√	√	√	-	-	-	-	-
			Power Window Lift	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			REC (Rear Electrical Centre)		√	√	√	√	-	-	-	-	-
			SDM (Airbag; Sensing&Diagnostic Module)		√	√	√	√	-	-	-	-	-
			SLM (Shift Lever Module)		√	√	√	√	-	-	-	-	-
			SRM (Sun Roof Module)		√	√	√	√	-	-	-	-	-
			Turn Indication	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			UEC (Underhood Electrical Centre)		√	√	√	√	-	-	-	-	-
			Wipers/Washer	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
		Chassis	ABS/TC/ESP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering)		√	√	√	√	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-
			Electronic Cruise Control	Engine	√	√	√	√	-	-	-	-	-
		Transmission	AF 23-5/33-5		√	√	√	√	√	-	-	-	-
			CVTronic		√	√	√	-	-	-	-	-	-
			CD-Changer		√	√	√	√	-	-	-	-	-
			GID/CID (Graphical/Colour Info Display)		√	√	√	√	√	-	-	-	-
			Global Positioning System GPS		√	√	√	-	-	-	-	-	-
			Radio 2020		√	√	√	-	-	-	-	-	-
			Radio 2620		√	√	√	-	-	-	-	-	-
			Radio CAR 2004		√	√	√	-	-	-	-	-	-

爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Infotainment System	Radio CART 2007	√	√	√	-	-	-	-	-	-	
			Radio CCR 2006	√	√	√	√	-	-	-	-	-	
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-	
			Radio CDR 2005	√	√	√	√	-	-	-	-	-	
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-	
			TID (Triple Info Display)	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
	Vivaro	Engine	F4R 720 (2.0l)	√	√	√	-	-	-	-	-	-	
			F9Q 760/762 (1.9l)	√	√	√	√	√	-	-	-	-	
			G9U 730 (2.5l)	√	√	√	-	-	-	-	-	-	
			Add On Heater	√	√	√	-	-	-	-	-	-	
		Body	Airbag	√	√	√	√	-	-	-	-	-	
			Body Control Module	√	√	√	√	√	-	-	-	-	
			Chassis	ABS/ESP	√	√	√	√	√	√	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-	-
					F9Q 774 (1.9l)	√	√	√	-	-	-	-	-

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Movano	Engine	G9T 750 (2.2l)	√	√	√	-	-	-	-	-	-
			G9U 750 (2.5l)	√	√	√	-	-	-	-	-	-
			G9U 754 (2.5l)	√	√	√	-	-	-	-	-	-
			ZD3 200/202 (3.0l)	√	√	√	-	-	-	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	-	-	-	-	-	-
			Park Pilot	√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP	√	√	√	√	√	√	√	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-
			Vauxhall VXR8	Engine	V8 GEN III	√	√	√	-	√	-	-
	Body	Audio System		√	√	√	√	√	-	-	-	-
		Body Control Module		√	√	√	√	√	-	-	-	-
		Instrument		√	√	√	√	√	-	-	-	-
		Occupant Climate Control		√	√	√	√	√	-	-	-	-
		Powertrain Interface Module		√	√	√	√	√	√	-	-	-
		SRS		√	√	√	√	-	-	-	-	-
	Chassis	ABS / ETC		√	√	√	√	-	-	-	-	-
		GEN III ABS / ETC		-	√	√	-	-	-	-	-	-
	transmission	GEN III Automatic Transmission		√	√	√	-	√	-	-	-	-
	Speedster /VX220	Engine	Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS 430	√	√	√	√	√	-	-	-	-
			Engine	Z 10 XEP	√	√	√	√	√	√	√	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Agila-B	Engine	Z 12 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Infotainment System	Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Engine		C 16 SEL	√	√	√	√	√	-	√	√	-
		Y 17 DT	√	√	√	√	√	-	√	-	-	
		Y 20 DTH	√	√	√	√	√	-	√	-	-	
		Y 22 DTR	√	√	√	√	√	-	-	-	-	
		Z 12 XE	√	√	√	√	√	-	-	-	-	
		Z 14 XE	√	√	√	√	√	-	-	-	-	
		Z 16 SE	√	√	√	√	√	-	-	-	-	
		Z 16 XE	√	√	√	√	√	-	-	-	-	
		Z 16 XEP	√	√	√	√	√	-	-	-	-	
		Z 16 YNG	√	√	√	√	√	-	-	-	-	
		Z 17 DTL	√	√	√	√	√	-	-	-	-	
		Z 18 XE	√	√	√	√	√	√	-	-	-	
		Z 18 XEL	√	√	√	√	√	-	-	-	-	
		Z 20 LET	√	√	√	√	√	-	-	-	-	
		Z 22 SE	√	√	√	√	√	√	-	-	-	
			Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G	Body	Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
Radio 620/635/635J	√		√	√	-	-	-	-	-	-		
Radio CAR 300	√		√	√	√	-	-	-	-	-		
Radio CAR 400	√		√	√	√	√	-	-	-	-		
Radio CCR 600	√		√	√	√	√	-	-	-	-		

 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Corsa-B	Engine	C 14 SE	√	√	√	-	√	-	-	-	-
			X 14 NE	√	√	√	√	√	-	-	-	-
			X 14 SZ	√	√	√	√	√	-	√	-	-
			X 16 NE	√	√	√	√	√	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	-	-	-	-	-	-
			Chassis	ABS-5.3	√	√	√	√	-	-	-	-
		Electronic Power Steering		√	√	√	√	-	-	-	-	-
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
	Radio CAR 400	√	√	√	√	√	-	-	-	-		

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Radio CCR 600	√	√	√	√	√	-	-	-	-	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	
	Corsa-C	Engine	Y 17 DT	√	√	√	√	√	-	√	-	-	
			Y 17 DTL	√	√	√	√	√	-	-	-	-	
			Z 10 XEP	√	√	√	√	√	√	√	√	-	
			Z 12 XE	√	√	√	√	√	-	-	-	-	
			Z 14 XE	√	√	√	√	√	-	-	-	-	
			Z 16 SE	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
			Body	Add On Heater	√	√	√	-	-	-	-	-	-
		Airbag		√	√	√	√	-	-	-	-	-	
		Body Control Module		√	√	√	√	√	-	√	-	-	
		Electronic Climate Control		√	√	√	√	√	-	-	-	-	
		Immobiliser		√	√	√	√	-	-	-	-	-	
		Instrument		√	√	√	√	√	-	-	-	-	
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-	
				CD-Changer	√	√	√	-	-	-	-	-	-
				Global Positioning System GPS	√	√	√	-	-	-	-	-	-
				Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
	Info Display CART/CCRT			√	√	√	-	-	-	-	-	-	
	Radio 2020			√	√	√	-	-	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio 2620	√	√	√	-	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
		Engine	Triple Info Display	√	√	√	√	-	-	-	-	-
			X 30 XE	√	√	√	√	-	-	-	-	-
			Y 22 DTH	√	√	√	√	√	-	√	-	-
			Y 25 DT	√	√	√	√	-	-	-	-	-
			Y 26 SE	√	√	√	√	√	-	-	-	-
			Y 32 SE	√	√	√	√	√	-	-	-	-
			Z 22 XE	√	√	√	√	√	-	-	-	-
		Body	Add On Heater	√	√	√	√	√	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Electronic Sun Roof	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	√	-
		Seat Memory	√	√	√	-	-	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Omega-B	Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Height Control Module	√	√	√	-	-	-	-	-	-
			Servotronic	√	√	√	-	-	-	-	-	-
		Transmission	5L40-E	√	√	√	-	-	-	-	-	-
			AR 25/35	√	-	√	-	-	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Engine	Y 20 DTH	√	√	√	√	-	-	-	-	-	
		Y 22 DTR	√	√	√	√	√	-	-	-	-	
		Z 16 XE	√	√	√	√	√	-	-	-	-	
		Z 16 YNG	√	√	√	√	√	-	-	-	-	
		Z 18 XE	√	√	√	√	√	√	-	-	-	

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
2003	Zafira		Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
		Body	Airbag	-	√	√	-	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-	
			Central Door Lock	√	√	√	√	√	-	-	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Engine Cooling Module	√	√	√	√	-	-	-	-	-	
			Headlamp Levelling Device(Left)	√	√	√	√	√	-	√	-	-	
			Headlamp Levelling Device(Right)	√	√	√	√	√	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
			Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
		ESP		√	√	√	√	√	-	-	-	-	
		Electronic Power Steering		√	√	√	√	√	-	-	-	-	
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-	
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-	
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Multi Info Display	√	√	√	√	-	-	-	-	-	
			Radio 420	√	√	√	-	-	-	-	-	-	
			Radio 435	√	√	√	-	-	-	-	-	-	
			Radio 520	√	√	√	-	-	-	-	-	-	
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-	
			Radio CAR 300	√	√	√	√	-	-	-	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Meriva	Engine	Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
		Body	Body Control Module	√	√	√	√	√	-	√	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainment	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
Frontera-B		nt System	Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	Y 22 DTH	√	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
		Body	Central Door Lock	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
		Transmissi on	AR 25/35	√	√	√	√	√	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	-	√	-	-	-	-
			Engine Cooling	√	√	√	√	-	-	-	-	-
			Y 20 DTH	√	√	√	√	√	-	-	-	-
			Y 22 DTR	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
		Engine	Z 16 XE	√	√	√	√	√	-	-	-	-	
			Y 30 DT	√	√	√	-	-	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	√	-	
			Z 20 NET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	√	-	-	
			Z 22 YH	√	√	√	√	√	-	-	-	-	
			Z 32 SE	√	√	√	√	-	-	-	-	-	
			AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-	
			Additional Heating	ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Anti Theft Warning System	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-
				PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
				REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			BCM (Body Control Module)	√	√	√	-	-	-	-	-	-	
			CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-	
			IPC (Instrument)	√	√	√	√	√	-	-	-	-	
			Central Door Lock	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-	
			DSM (Driver Seat Module)	√	√	√	√	-	-	-	-	-	
			ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-	
			Electric Adjustable Mirrors	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			Electrical Horn	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-C / Signum	Body	Electronic Seat Memory/Seat Heating	REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			Exterior Lighting	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobiliser	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	IPC (Instrument)	√	√	√	√	√	-	-	-	-
				SDM (Airbag)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	-	-	-	-	-
			PDM (Passenger Door Module)		√	√	√	√	-	-	-	-	-
			Power Window Lift	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			REC (Rear Electrical Centre)		√	√	√	√	-	-	-	-	-
			SDM (Airbag; Sensing&Diagnostic Module)		√	√	√	√	-	-	-	-	-
			SLM (Shift Lever Module)		√	√	√	√	-	-	-	-	-
			SRM (Sun Roof Module)		√	√	√	√	-	-	-	-	-
			Turn Indication	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			UEC (Underhood Electrical Centre)		√	√	√	-	-	-	-	-	-
			Wipers/Washer	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
		Chassis	ABS/TC/ESP		√	√	√	√	√	-	-	-	-
			EHPS (Electrohydraulic Power Steering)		√	√	√	√	-	-	-	-	-
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-

 爱夫卡										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Electronic Cruise Control	Engine	√	√	√	√	-	-	-	-	-
		Transmission	AF 23-5/33-5		√	√	√	√	√	-	-	-	-
		Infotainment System	CD-Changer		√	√	√	√	-	-	-	-	-
			GID/CID (Graphical/Colour Info Display)		√	√	√	√	√	-	-	-	-
			Global Positioning System GPS		√	√	√	-	-	-	-	-	-
			Radio 2020		√	√	√	-	-	-	-	-	-
			Radio 2620		√	√	√	-	-	-	-	-	-
			Radio CAR 2004		√	√	√	-	-	-	-	-	-
			Radio CART 2007		√	√	√	-	-	-	-	-	-
			Radio CCR 2006		√	√	√	√	-	-	-	-	-
			Radio CCRT 2008		√	√	√	-	-	-	-	-	-
			Radio CDR 2005		√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015		√	√	√	-	-	-	-	-	-
			TID (Triple Info Display)		√	√	√	-	-	-	-	-	-
		Telematic Unit		√	√	√	-	-	-	-	-	-	
	Vivaro	Engine	F4R 720 (2.0l)		√	√	√	-	-	-	-	-	-
			F9Q 760/762 (1.9l)		√	√	√	√	√	-	-	-	-
			G9U 730 (2.5l)		√	√	√	-	-	-	-	-	-
		Body	Add On Heater		√	√	√	-	-	-	-	-	-
		Chassis	ABS/ESP		√	√	√	√	√	√	√	-	-
			CD-Changer		√	√	√	-	-	-	-	-	-
			Global Positioning System GPS		√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display		√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT		√	√	√	-	-	-	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Movano	Engine	F9Q 772 (1.9l)	√	√	√	-	-	-	-	-	-
			G9T 720 (2.2l)	√	√	√	-	-	-	-	-	-
			G9T 722 (2.2l)	√	√	√	-	-	-	-	-	-
			G9U 720 (2.5l)	√	√	√	-	-	-	-	-	-
			G9U 724 (2.5l)	√	√	√	-	-	-	-	-	-
		Body	Airbag AC4	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
		Chassis	ABS.	√	√	√	-	-	-	-	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-
	Speedster /VX220	Engine	Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS 430	√	√	√	√	√	-	-	-	-
	Engine	Z 10 XEP	√	√	√	√	√	√	√	√	-	
		Z 12 XE	√	√	√	√	√	-	-	-	-	
	Body	Airbag	√	√	√	√	-	-	-	-	-	
		Immobiliser	√	√	√	√	-	-	-	-	-	

									Automak er			Opel
FCAR F3 Diagnostic List									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Agila-B		Instrument	√	√	√	√	√	-	-	-	-
			ABS	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Infotainme nt System	Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Astra-F	Engine	X 14 NZ	√	√	√	√	√	-	-	-	-
			X 16 NE	√	√	√	√	√	-	-	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	√	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-2E	√	√	√	√	√	-	-	-	-
		Infotainme nt System	Multi Info Display	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			C 16 SEL	√	√	√	√	√	-	√	√	-
			Y 17 DT	√	√	√	√	√	-	√	-	-
			Y 20 DTH	√	√	√	√	√	-	√	-	-
			Y 20 DTL	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Astra-G	Engine	Z 12 XE	√	√	√	√	√	-	-	-	-	
			Z 14 XE	√	√	√	√	√	-	-	-	-	
			Z 16 SE	√	√	√	√	√	-	-	-	-	
			Z 16 XE	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
			Z 18 XEL	√	√	√	√	√	-	-	-	-	
			Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
		Body	Add On Heater	√	√	√	-	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-	-

FCAR 爱夫卡										Automak er			Opel
FCAR F3 Diagnostic List										Softwar e			V6.1
Menu			Function										
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others	
		Infotainme nt System	Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Multi Info Display	√	√	√	√	-	-	-	-	-	
			Radio 420	√	√	√	-	-	-	-	-	-	
			Radio 435	√	√	√	-	-	-	-	-	-	
			Radio 520	√	√	√	-	-	-	-	-	-	
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-	
			Radio CAR 300	√	√	√	√	-	-	-	-	-	
			Radio CAR 400	√	√	√	√	√	-	-	-	-	
			Radio CCR 600	√	√	√	√	√	-	-	-	-	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
		Engine	C 14 SE	√	√	√	-	√	-	-	-	-	
			X 14 NE	√	√	√	√	√	-	-	-	-	
			X 14 SZ	√	√	√	√	√	-	√	-	-	
			X 16 NE	√	√	√	√	√	-	-	-	-	
		Body	Airbag SAB6	√	√	√	√	-	-	-	-	-	
			Airbag-S	√	√	√	√	-	-	-	-	-	
			Anti Theft Warning	√	√	√	√	-	√	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
		Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-	
			Electronic Power Steering	√	√	√	√	-	-	-	-	-	
					Global Positioning System GPS	√	√	√	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-B	Infotainment System	Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
		Engine	Y 17 DT	√	√	√	√	√	-	√	-	-
			Y 17 DTL	√	√	√	√	√	-	-	-	-
			Z 10 XEP	√	√	√	√	√	√	√	√	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 14 XE	√	√	√	√	√	-	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	√	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Instrument	√	√	√	√	√	-	-	-	-	
					ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-C	Chassis	Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			MTA (Easytronic)	√	√	√	√	√	-	-	-	-
			Infotainment System	CD-Changer	√	√	√	-	-	-	-	-
		Global Positioning System GPS		√	√	√	-	-	-	-	-	-
		Graphical/Colour Info Display		√	√	√	-	-	-	-	-	-
		Info Display CART/CCRT		√	√	√	-	-	-	-	-	-
		Radio 2020		√	√	√	-	-	-	-	-	-
		Radio 2620		√	√	√	-	-	-	-	-	-
		Radio CAR 2003		√	√	√	√	-	-	-	-	-
		Radio CAR 2004		√	√	√	-	-	-	-	-	-
		Radio CART 2007		√	√	√	-	-	-	-	-	-
		Radio CCR 2006		√	√	√	√	-	-	-	-	-
		Radio CCRT 2008		√	√	√	-	-	-	-	-	-
		Radio CDR 2005		√	√	√	√	-	-	-	-	-
		Radio NCDC 2011 / NCDC 2013 / NCDC 2015		√	√	√	-	-	-	-	-	-
		Telematic Unit		√	√	√	-	-	-	-	-	-
		Triple Info Display	√	√	√	√	-	-	-	-	-	
		Engine	X 30 XE	√	√	√	√	-	-	-	-	-
			Y 22 DTH	√	√	√	√	√	-	√	-	-
			Y 25 DT	√	√	√	√	-	-	-	-	-
			Y 26 SE	√	√	√	√	√	-	-	-	-
			Y 32 SE	√	√	√	√	√	-	-	-	-
			Z 22 XE	√	√	√	√	√	-	-	-	-
			Add On Heater	√	√	√	√	√	-	-	-	-
		Airbag	-	√	√	-	-	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
2002	Omega-B	Body	Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Electronic Sun Roof	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	√	-
			Seat Memory	√	√	√	-	-	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Height Control Module	√	√	√	-	-	-	-	-	-
			Servotronic	√	√	√	-	-	-	-	-	-
		Transmission	5L40-E	√	√	√	-	-	-	-	-	-
			AR 25/35	√	-	√	-	-	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
	Zafira	Engine	Y 20 DTH	√	√	√	√	√	-	√	-	-	
			Y 22 DTR	√	√	√	√	√	-	-	-	-	
			Z 16 XE	√	√	√	√	√	-	-	-	-	
			Z 16 YNG	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	-	-	
			Z 20 LET	√	√	√	√	√	-	-	-	-	
			Z 22 SE	√	√	√	√	√	√	-	-	-	
			Body	Airbag	-	√	√	-	-	-	-	-	-
				Anti Theft Warning	√	√	√	√	√	-	-	-	-
		Central Door Lock		√	√	√	√	√	-	-	-	-	
		Engine Cooling Module		√	√	√	√	-	-	-	-	-	
		Immobiliser		√	√	√	√	-	-	-	-	-	
		Instrument		√	√	√	√	√	-	-	-	-	
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-	
			ESP	√	√	√	√	√	-	-	-	-	
			Electronic Power Steering	√	√	√	√	√	-	-	-	-	
		Transmission		AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
				CD-Changer	√	√	√	-	-	-	-	-	-
				Global Positioning System GPS	√	√	√	-	-	-	-	-	-
				Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
				Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
				Multi Info Display	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Frontera-B	Engine	Y 22 DTH	√	√	√	√	√	-	√	-	-
		Body	Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
		Transmission	AR 25/35	√	√	√	√	√	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
		Radio CCRT 700	√	√	√	√	√	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	
			Telematic Unit	√	√	√	-	-	-	-	-	-	
			Triple Info Display	√	√	√	-	√	-	-	-	-	
		Engine	Engine Cooling	√	√	√	√	-	-	-	-	-	
			Y 20 DTH	√	√	√	√	√	-	-	-	-	
			Y 22 DTR	√	√	√	√	√	-	-	-	-	
			Z 16 XE	√	√	√	√	√	-	-	-	-	
			Z 18 XE	√	√	√	√	√	√	-	√	-	
			Z 22 SE	√	√	√	√	√	√	√	-	-	
			Z 32 SE	√	√	√	√	-	-	-	-	-	
				AHL/AFL (Headlamp Levelling)	√	√	√	-	-	-	-	-	-
				Additional Heating	ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-
		BCM (Body Control Module)			√	√	√	-	-	-	-	-	-
		Anti Theft Warning System		BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
				DDM (Driver Door Module)	√	√	√	√	-	-	-	-	-
				PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
				REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
		BCM (Body Control Module)		√	√	√	-	-	-	-	-	-	
		CIM (Steering Column Module)		√	√	√	√	-	-	-	-	-	
		IPC (Instrument)		√	√	√	√	√	-	-	-	-	
		Central Door Lock		PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
		DDM (Driver Door Module)		√	√	√	√	-	-	-	-	-	
		DSM (Driver Seat Module)		√	√	√	√	-	-	-	-	-	
		ECC (Electronic Climate Control)	√	√	√	√	√	-	-	-	-		

										Automaker			Opel
FCAR F3 Diagnostic List										Software			V6.1
Menu			Function										
Series	Year	System	Sub System		ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
Vectra-C / Signum		Body	Electric Adjustable Mirrors	PDM (Passenger Door Module)	√	√	√	√	-	-	-	-	-
			Electrical Horn	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
				EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Electronic Seat Memory/Seat Heating	REC (Rear Electrical Centre)	√	√	√	√	-	-	-	-	-
			Exterior Lighting	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			Heating, Ventilation and Air Cond.	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			Immobiliser	CIM (Steering Column Module)	√	√	√	√	-	-	-	-	-
			Instrument	IPC (Instrument)	√	√	√	√	√	-	-	-	-
				SDM (Airbag)	√	√	√	√	√	-	-	-	-
				BCM (Body Control Module)	√	√	√	√	√	-	-	-	-
			Interior Lighting	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			PAS (Park Pilot)		√	√	√	√	-	-	-	-	-
			PDM (Passenger Door Module)		√	√	√	√	-	-	-	-	-
			Power Window Lift	BCM (Body Control Module)	√	√	√	-	-	-	-	-	-
			REC (Rear Electrical Centre)		√	√	√	√	-	-	-	-	-
			SLM (Shift Lever Module)		√	√	√	√	-	-	-	-	-
			SRM (Sun Roof Module)		√	√	√	√	-	-	-	-	-
			Turn Indication	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-
			UEC (Underhood Electrical Centre)		√	√	√	-	-	-	-	-	-
			Wipers/Washer	EC (Underhood Electrical Centre)	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel			
FCAR F3 Diagnostic List									Software			V6.1			
Menu			Function												
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others			
		Chassis	ABS/TC/ESP		√	√	√	√	√	-	-	-	-		
			EHPS (Electrohydraulic Power Steering)		√	√	√	√	-	-	-	-	-		
			TPMS (Tyre Pressure Monitoring System)		√	√	√	-	-	-	-	-	-		
			Electronic Cruise Control	Engine	√	√	√	√	-	-	-	-	-		
		Transmission	AF 23-5/33-5			√	√	√	√	√	-	-	-	-	
		Infotainment System	CD-Changer			√	√	√	√	-	-	-	-	-	-
			GID/CID (Graphical/Colour Info Display)			√	√	√	√	√	-	-	-	-	-
			Global Positioning System GPS			√	√	√	-	-	-	-	-	-	-
			Radio 2020			√	√	√	-	-	-	-	-	-	-
			Radio 2620			√	√	√	-	-	-	-	-	-	-
			Radio CART 2007			√	√	√	-	-	-	-	-	-	-
			Radio CCR 2006			√	√	√	√	-	-	-	-	-	-
			Radio CCRT 2008			√	√	√	-	-	-	-	-	-	-
			Radio CDR 2005			√	√	√	√	-	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015			√	√	√	-	-	-	-	-	-	-
			TID (Triple Info Display)			√	√	√	-	-	-	-	-	-	-
			Telematic Unit			√	√	√	-	-	-	-	-	-	-
	Campo	Engine	4JA1-TC Bosch		√	√	√	-	-	-	-	-	-	-	
		Body	Immobiliser		√	√	√	-	-	-	-	-	-	-	
		Engine	F9Q 760/762 (1.9l)		√	√	√	√	√	-	-	-	-	-	
			Body	Add On Heater		√	√	√	-	-	-	-	-	-	-
		Airbag		√	√	√	√	-	-	-	-	-	-		
		Body Control Module		√	√	√	√	√	-	-	-	-	-		
		Chassis	ABS		√	√	√	√	√	-	-	-	-	-	

 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vivaro	Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
	Triple Info Display	√	√	√	√	-	-	-	-	-		
	Movano	Engine	F9Q 770 (1.9l)	√	√	√	-	-	-	-	-	-
			F9Q 772 (1.9l)	√	√	√	-	-	-	-	-	-
			G9T 720 (2.2l)	√	√	√	-	-	-	-	-	-
			G9T 722 (2.2l)	√	√	√	-	-	-	-	-	-
			G9U 720 (2.5l)	√	√	√	-	-	-	-	-	-
		Body	Airbag AC4	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
		Chassis	ABS.	√	√	√	-	-	-	-	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-
	Speedster /VX220	Engine	Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS 430	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Agila-B	Engine	Z 10 XEP	√	√	√	√	√	√	√	√	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Infotainme nt System	Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Astra-F	Engine	X 14 NZ	√	√	√	√	√	-	-	-	-
			X 16 NE	√	√	√	√	√	-	-	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	√	-
			Airbag-S	√	√	√	√	-	-	-	-	-
		Body	Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Chassis	ABS-2E	√	√	√	√	√	-	-	-
		Infotainme nt System	Multi Info Display	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
		Radio CDR 500	√	√	√	√	√	-	-	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G	Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 18 XE1	√	√	√	√	√	-	√	-	-
			Y 17 DT	√	√	√	√	√	-	√	-	-
			Y 20 DTH	√	√	√	√	√	-	√	-	-
			Y 20 DTL	√	√	√	√	√	-	-	-	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 14 XE	√	√	√	√	√	-	-	-	-
			Z 16 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 18 XEL	√	√	√	√	√	-	-	-	-
			Z 20 LET	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
			Softtop Controller	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
				Engine	C 14 SE	√	√	√	-	√	-	-
	X 14 NE	√			√	√	√	√	-	-	-	-
	X 14 SZ	√			√	√	√	√	-	√	-	-
	X 16 NE	√			√	√	√	√	-	-	-	-
	Body	Airbag SAB6		√	√	√	√	-	-	-	-	-
		Airbag-S		√	√	√	√	-	-	-	-	-
		Anti Theft Warning		√	√	√	√	-	√	-	-	-

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-B	Chassis	Immobiliser	√	√	√	√	-	-	-	-	-
			ABS-5.3	√	√	√	√	-	-	-	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
		Engine	Y 17 DT	√	√	√	√	√	-	√	-	-
			Y 17 DTL	√	√	√	√	√	-	-	-	-
			Z 10 XEP	√	√	√	√	√	√	√	√	-
			Z 12 XE	√	√	√	√	√	-	-	-	-
			Z 14 XE	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmissi	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-

爱夫卡									Automak er			Opel
FCAR F3 Diagnostic List									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Corsa-C	on	MTA (Easytronic)	√	√	√	√	√	-	-	-	-
		Infotainme nt System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio 2020	√	√	√	-	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	X 20 XEV	√	√	√	√	√	-	√	-	-
			X 30 XE	√	√	√	√	-	-	-	-	-
			Y 22 DTH	√	√	√	√	√	-	√	-	-
			Y 26 SE	√	√	√	√	√	-	-	-	-
			Y 32 SE	√	√	√	√	√	-	-	-	-
			Z 22 XE	√	√	√	√	√	-	-	-	-
			Add On Heater	√	√	√	√	√	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
2001	Omega-B	Body	Electronic Sun Roof	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Instrument	√	√	√	√	√	-	-	√	-
			Seat Memory	√	√	√	-	-	-	-	-	-
			Immobiliser (KW82)	√	√	√	√	-	-	-	-	-
			Immobiliser (KWP)	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			Height Control Module	√	√	√	-	-	-	-	-	-
			Servotronic	√	√	√	-	-	-	-	-	-
		Transmission	AR 25/35	√	√	√	√	√	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-
			Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
Radio NCDC 2011 / NCDC 2013 / NCDC 2015	√		√	√	-	-	-	-	-	-		
Telematic Unit	√	√	√	-	-	-	-	-	-			
Triple Info Display	√	√	√	√	-	-	-	-	-			

FCAR 爱夫卡									Automaker			Opel
									Software			V6.1
FCAR F3 Diagnostic List												
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Zafira	Engine	Y 22 DTR	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 16 YNG	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	C 20 SEL	√	√	√	√	√	-	√	-	-
			C 22 SEL	√	√	√	√	√	-	√	-	-
			X 16 XEL	√	√	√	√	√	-	√	-	-
			X 18 XE	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	√	-	-
			Y 16 XE	√	√	√	√	√	-	-	-	-
			Y 20 DTH	√	√	√	√	√	-	√	-	-
			Y 22 DTR	√	√	√	√	√	-	-	-	-
			Y 26 SE	√	√	√	√	√	-	-	-	-
			Z 16 XE	√	√	√	√	√	-	-	-	-
			Z 18 XE	√	√	√	√	√	√	-	-	-
			Z 18 XEL	√	√	√	√	√	-	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-

爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-B		Headlamp Levelling Device(Left)	√	√	√	√	√	√	-	-	-
			Headlamp Levelling Device(Right)	√	√	√	√	√	-	-	-	-
			Instrument	√	√	√	-	-	-	-	-	-
			Immobiliser (KW82)	√	√	√	√	-	-	-	-	-
			Immobiliser (KWP)	√	√	√	√	-	-	-	-	-
		Chassis	ABS 430	√	√	√	√	√	-	-	-	-
			ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
	Campo	Body	Immobiliser	√	√	√	-	-	-	-	-	-	
	Frontera-B	Engine	Y 22 DTH	√	√	√	√	√	√	-	√	-	-
		Body	Anti Theft Warning	√	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	-	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-	-
		Transmission	AR 25/35	√	√	√	√	√	√	-	-	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-	-
			Triple Info Display	√	√	√	-	√	-	-	-	-	-
		Engine	F9Q 760/762 (1.9l)	√	√	√	√	√	√	-	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-	-
			Airbag	√	√	√	√	-	-	-	-	-	-
			Body Control Module	√	√	√	√	√	-	-	-	-	-
		Chassis	ABS	√	√	√	√	√	√	-	-	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel		
FCAR F3 Diagnostic List									Software			V6.1		
Menu			Function											
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others		
	Vivaro	Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-		
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-		
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-		
			Radio CAR 2004	√	√	√	-	-	-	-	-	-		
			Radio CART 2007	√	√	√	-	-	-	-	-	-		
			Radio CCR 2006	√	√	√	√	-	-	-	-	-		
			Radio CDR 2005	√	√	√	√	-	-	-	-	-		
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-		
			Telematic Unit	√	√	√	-	-	-	-	-	-		
			Triple Info Display	√	√	√	√	-	-	-	-	-		
	Movano	Engine	F9Q 770 (1.9l)	√	√	√	-	-	-	-	-	-		
			G9T 720 (2.2l)	√	√	√	-	-	-	-	-	-		
			S8U (2.5l)	-	√	√	-	-	-	-	-	-		
			S9W (2.8l TPPEGR Sagem)	-	√	√	-	-	-	-	-	-		
			Airbag AC4	√	√	√	√	-	-	-	-	-		
		Body	Immobiliser	√	√	√	-	-	-	-	-	-		
			ABS.	√	√	√	-	-	-	-	-	-		
		Chassis	Pneumatic Suspension	√	√	√	-	-	-	-	-	-		
			Speedster /VX220	Engine	Z 22 SE	√	√	√	√	√	√	-	-	-
				Body	Airbag	-	√	√	-	-	-	-	-	-
	Anti Theft Warning	√			√	√	-	-	-	-	-	-		
	Immobiliser	√			√	√	√	-	-	-	-	-		
	Chassis	ABS 430	√	√	√	√	√	-	-	-	-			
			Engine	Z 10 XEP	√	√	√	√	√	√	√	√	-	
Z 12 XE	√			√	√	√	√	-	-	-	-			
Airbag	√			√	√	√	-	-	-	-	-			

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Agila-B	Body	Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS	√	√	√	√	√	-	√	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Infotainment System	Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
	Astra-F	Engine	Triple Info Display	√	√	√	√	-	-	-	-	-
			16 NZR	√	√	√	√	√	-	√	-	-
			X 14 NZ	√	√	√	√	√	-	-	-	-
			X 16 NE	√	√	√	√	√	-	-	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
		Body	X 16 XEL	√	√	√	√	√	-	√	√	-
			Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
		Chassis	Immobiliser	√	√	√	√	-	-	-	-	-
			ABS-2E	√	√	√	√	√	-	-	-	-
		Transmission	AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
		Infotainment System	Multi Info Display	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G	Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
			X 12 XE	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	-	-
			X 17 DTL	√	√	√	√	√	-	√	-	-
			X 18 XE1	√	√	√	√	√	-	√	-	-
			X 20 DTL	√	√	√	√	√	-	√	-	-
			X 20 XER	√	√	√	√	√	-	-	-	-
			X 20 XEV	√	√	√	√	√	-	-	-	-
			Y 17 DT	√	√	√	√	√	-	-	-	-
			Y 20 DTH	√	√	√	√	√	√	-	-	-
			Z 22 SE	√	√	√	√	√	√	-	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	Instrument	√	√	√	√	√	-	-	-	-
			ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
					Electronic Power Steering	√	√	√	√	√	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Engine	C 14 SE	√	√	√	-	√	-	-	-	-	
		C 14 SEL	√	√	√	√	√	-	√	-	-	
		C 16 SEL	√	√	√	√	√	-	√	-	-	
		X 10 XE	√	√	√	√	√	-	√	√	-	
		X 12 XE	√	√	√	√	√	-	√	-	-	
		X 14 NE	√	√	√	√	√	-	-	-	-	
		X 14 SZ	√	√	√	√	√	-	√	-	-	
		X 14 XE	√	√	√	√	√	-	√	√	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Corsa-B		X 16 NE	√	√	√	√	√	-	-	-	-
			X 16 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag SAB6	√	√	√	√	-	-	-	-	-
			Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Chassis	ABS-5.3	√	√	√	√	-	-	-	-
		Electronic Power Steering		√	√	√	√	-	-	-	-	-
		Transmissio	AF 13/14/20	√	√	√	-	-	-	-	-	-
			AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
		Infotainme nt System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
		Engine	X 20 DTH	√	√	√	√	√	-	√	-	-
	X 20 XEV		√	√	√	√	√	-	√	-	-	
	X 25 XE		√	√	√	√	-	-	-	-	-	

爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
2000	Omega-B		X 30 XE	√	√	√	√	-	-	-	-	-
			Y 22 XE	√	√	√	√	√	-	-	-	-
		Body	Add On Heater	√	√	√	√	√	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
			Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Electronic Sun Roof	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Instrument	√	√	√	√	√	-	-	√	-
			Seat Memory	√	√	√	-	-	-	-	-	-
			Immobiliser (KW82)	√	√	√	√	-	-	-	-	-
			Immobiliser (KWP)	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			Height Control Module	√	√	√	-	-	-	-	-	-
			Servotronic	√	√	√	-	-	-	-	-	-
		Transmissi on	AR 25/35	√	√	√	√	√	-	-	-	-
		Infotainme	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 2003	√	√	√	√	-	-	-	-	-
			Radio CAR 2004	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		nt System	Radio CART 2007	√	√	√	-	-	-	-	-	-
			Radio CCR 2006	√	√	√	√	-	-	-	-	-
			Radio CCRT 2008	√	√	√	-	-	-	-	-	-
			Radio CDR 2005	√	√	√	√	-	-	-	-	-
			Radio NCDR 2011 / NCDC 2013 / NCDC 2015	√	√	√	-	-	-	-	-	-
			Telematic Unit	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Zafira	Engine	X 16 XEL	√	√	√	√	√	-	√	-	-
			X 18 XE1	√	√	√	√	√	-	√	-	-
			X 20 DTL	√	√	√	√	√	-	√	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			ESP	√	√	√	√	√	-	-	-	-
			Electronic Power Steering	√	√	√	√	√	-	-	-	-
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
			CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-

 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	16 LZ 2	√	√	√	√	√	-	-	-	-
			20 NEJ	√	√	√	√	-	-	-	-	-
			C 20 SEL	√	√	√	√	√	-	√	-	-
			C 22 SEL	√	√	√	√	√	-	√	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	-	-
			X 18 XE1	√	√	√	√	√	-	√	-	-
			X 20 DTH	√	√	√	√	√	-	√	-	-
			X 20 DTL	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	√	-	-
			X 25 XE	√	√	√	√	√	-	√	-	-
			Y 16 XE	√	√	√	√	√	-	-	-	-
				Add On Heater	√	√	√	-	-	-	-	-

爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-B	Body	Airbag SAB6	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Headlamp Levelling Device(Left)	√	√	√	√	√	√	-	-	-
			Headlamp Levelling Device(Right)	√	√	√	√	√	-	-	-	-
			Instrument	√	√	√	-	-	-	-	-	-
			Immobiliser (KW82)	√	√	√	√	-	-	-	-	-
			Immobiliser (KWP)	√	√	√	√	-	-	-	-	-
		Chassis	ABS 430	√	√	√	√	√	-	-	-	-
			ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-
		Infotainment System	CD-Changer	√	√	√	-	-	-	-	-	-
			Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Graphical/Colour Info Display	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Radio NCDR 1100/1500	√	√	√	-	-	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
	Tigra	Engine	C 14 SEL	√	√	√	√	√	-	√	-	-	
			C 16 SEL	√	√	√	√	√	-	√	-	-	
			X 14 XE	√	√	√	√	√	-	√	√	-	
			X 16 XE	√	√	√	√	√	-	-	-	-	
			Airbag SAB6	√	√	√	√	-	-	-	-	-	
		Body	Airbag-S	√	√	√	√	-	-	-	-	-	
			Anti Theft Warning	√	√	√	√	-	√	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-	
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Radio CAR 300	√	√	√	√	-	-	-	-	-	
			Radio CAR 400	√	√	√	√	√	-	-	-	-	
			Radio CCR 600	√	√	√	√	√	-	-	-	-	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
		Arena	Engine	F8Q (1.9l)	√	√	√	-	-	-	-	-	-
				S8U (2.5l)	-	√	√	-	-	-	-	-	-
			Body	Airbag AC4	-	√	√	-	-	-	-	-	-
	Immobiliser			√	√	√	-	-	-	-	-	-	

爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Movano	Engine	S8U (2.5l)	-	√	√	-	-	-	-	-	-	
			S9W (2.8l TPPEGR Sagem)	-	√	√	-	-	-	-	-	-	
			S9W 700 (2.8l Mag. Marelli)	√	√	√	-	-	-	-	-	-	
		Body	Airbag AC4	√	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-	-
		Chassis	ABS.	√	√	√	-	-	-	-	-	-	-
			Pneumatic Suspension	√	√	√	-	-	-	-	-	-	-
	Frontera-B	Engine	X 22 DTH	√	√	√	√	√	-	√	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-	-
		Body	Central Door Lock	√	√	√	-	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-	-
		Transmission	AR 25/35	√	√	√	√	√	-	-	-	-	-
		Infotainment System	Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-	-
			Triple Info Display	√	√	√	-	√	-	-	-	-	-
		Engine	16 NZR	√	√	√	√	√	-	√	-	-	
			18 SE	√	√	√	√	-	-	-	-	-	-
			C 16 SE	√	√	√	√	√	-	-	-	-	-
			C 18 SEL	√	√	√	√	√	-	√	√	-	-
			X 14 NZ	√	√	√	√	√	-	-	-	-	-

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-F		X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	√	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-2E	√	√	√	√	√	-	-	-	-
		Transmission	AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
		Infotainment System	Multi Info Display	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
		Engine	C 16 SEL	√	√	√	√	√	-	√	√	-
			X 12 XE	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	-	-
			X 17 DTL	√	√	√	√	√	-	√	-	-
			X 18 XE1	√	√	√	√	√	-	√	-	-
			X 20 DTL	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G	Body	Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
			C 14 SE	√	√	√	-	√	-	-	-	-
			C 14 SEL	√	√	√	√	√	-	√	-	-
			C 16 SEL	√	√	√	√	√	-	√	-	-
			X 10 XE	√	√	√	√	√	-	√	√	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-B	Engine	X 10 XE S	√	√	√	-	-	-	-	-	-
			X 12 XE	√	√	√	√	√	-	√	-	-
			X 14 SZ	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	√	-
			X 16 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag SAB6	√	√	√	√	-	-	-	-	-
			Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
			AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
		20 SE	√	√	√	√	-	-	-	-	-	
		X 20 DTH	√	√	√	√	√	-	√	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel	
									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
	Omega-B	Engine	X 20 SE	√	√	√	-	-	-	-	-	-	
			X 20 XEV	√	√	√	√	√	-	√	-	-	
			X 25 XE	√	√	√	√	-	-	-	-	-	
			X 30 XE	√	√	√	√	-	-	-	-	-	
		Body	Add On Heater	√	√	√	√	√	-	-	-	-	
			Airbag SAB6	√	√	√	√	-	-	-	-	-	
			Anti Theft Warning	√	√	√	√	√	√	-	-	-	
			Central Door Lock	√	√	√	√	√	-	-	-	-	
			Electronic Climate Control	√	√	√	√	√	-	-	-	-	
			Electronic Sun Roof	√	√	√	√	-	-	-	-	-	
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	√	-	
			Seat Memory	√	√	√	-	-	-	-	-	-	
			Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
				Cruise Control	√	√	√	-	-	-	-	-	-
		Height Control Module		√	√	√	-	-	-	-	-	-	
		Servotronic		√	√	√	-	-	-	-	-	-	
		Transmission	AR 25/35	√	√	√	√	√	-	-	-	-	
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Multi Info Display	√	√	√	√	-	-	-	-	-	
			Radio CAR 300	√	√	√	√	-	-	-	-	-	
			Radio CAR 400	√	√	√	√	√	-	-	-	-	
			Radio CCR 600	√	√	√	√	√	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
1999			Radio CCR 800	√	√	√	-	-	-	-	-	-	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
	Zafira	Engine	X 16 XEL	√	√	√	√	√	-	√	-	-	
			X 18 XE1	√	√	√	√	√	-	√	-	-	
		Body	Airbag SAB6	√	√	√	√	-	-	-	-	-	
			Anti Theft Warning	√	√	√	√	√	-	-	-	-	
			Central Door Lock	√	√	√	√	√	-	-	-	-	
			Engine Cooling Module	√	√	√	√	-	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
			Instrument	√	√	√	√	√	-	-	-	-	
			Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
				Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13-II/17/20/22 CAN	√	√	√	√	√	-	√	-	-	
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-	
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-	
			Multi Info Display	√	√	√	√	-	-	-	-	-	
			Radio CAR 300	√	√	√	√	-	-	-	-	-	
			Radio CAR 400	√	√	√	√	√	-	-	-	-	
			Radio CCR 600	√	√	√	√	√	-	-	-	-	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
			Triple Info Display	√	√	√	√	-	-	-	-	-	
		16 LZ 2	√	√	√	√	√	-	-	-	-		

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-B	Engine	20 NEJ	√	√	√	√	-	-	-	-	-
			C 20 SEL	√	√	√	√	√	-	√	-	-
			C 22 SEL	√	√	√	√	√	-	√	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	√	-
			X 18 XE	√	√	√	√	√	-	√	-	-
			X 18 XE1	√	√	√	√	√	-	√	-	-
			X 20 DTH	√	√	√	√	√	-	√	-	-
			X 20 DTL	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	√	-	-
			X 25 XE	√	√	√	√	√	-	√	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Instrument	√	√	√	-	-	-	-	-	-
			Immobiliser (KW82)	√	√	√	√	-	-	-	-	-
			Immobiliser (KWP)	√	√	√	√	-	-	-	-	-
		Chassis	ABS 415	√	√	√	√	-	-	-	-	-
			ABS 430	√	√	√	√	√	-	-	-	-
			ABS-5-TC	√	√	√	√	-	-	-	-	-
			ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
			AF 13II/20/22/30	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
	Triple Info Display	√	√	√	√	-	-	-	-	-		
	Tigra	Engine	C 14 SEL	√	√	√	√	√	-	√	-	-
			C 16 SEL	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	√	-
			X 16 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag SAB6	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
		Infotainment System	Global Positioning System GPS	√	√	√	-	-	-	-	-	-
			Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡									Automaker			Opel	
FCAR F3 Diagnostic List									Software			V6.1	
Menu			Function										
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others	
			Radio CCRT 700	√	√	√	√	√	-	-	-	-	
			Radio CDR 500	√	√	√	√	√	-	-	-	-	
	Monterey	Body	Anti Theft Warning	√	√	√	-	-	-	-	-	-	
			Immobiliser	√	√	√	√	-	-	-	-	-	
		Chassis	ABS 5	√	√	√	√	√	-	-	-	-	
		Sintra	Engine	X 22 DTH	√	√	√	√	√	-	√	-	-
	X 22 XE			√	√	√	-	-	-	-	-	-	
	X 30 XE			√	√	√	-	-	-	-	-	-	
	Body		Airbag	-	√	√	-	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-	-
	Chassis		Cruise Control	√	√	√	-	-	-	-	-	-	-
	Transmission		AF 13II/20/22/30	√	√	√	√	√	-	-	-	-	-
	Infotainment System		Multi Info Display	√	√	√	-	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-	-
	Arena	Engine	F8Q (1.9l)	√	√	√	-	-	-	-	-	-	-
			S8U (2.5l)	-	√	√	-	-	-	-	-	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-	-
			Airbag AC4	-	√	√	-	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-	-
	Movano	Engine	S8U (2.5l)	-	√	√	-	-	-	-	-	-	-
			S9W 700 (2.8l Mag. Marelli)	√	√	√	-	-	-	-	-	-	-
		Body	Airbag AC4	√	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Chassis	ABS.	√	√	√	-	-	-	-	-	-
	Frontera-B	Engine	X 22 DTH	√	√	√	√	√	-	√	-	-
		Body	Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
		Transmission	AR 25/35	√	√	√	√	√	-	-	-	-
		Infotainment System	Info Display CART/CCRT	√	√	√	-	-	-	-	-	-
			Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Triple Info Display	√	√	√	-	√	-	-	-	-
	Engine	14 SE	√	√	√	√	√	-	-	-	-	
		16 LZ 2	√	√	√	√	√	-	-	-	-	
		16 NZR	√	√	√	√	√	-	√	-	-	
		18 SE	√	√	√	√	-	-	-	-	-	
		C 14 SE	√	√	√	√	√	-	-	-	-	
		C 16 SE	√	√	√	√	√	-	-	-	-	
		C 18 SEL	√	√	√	√	√	-	√	√	-	
		X 14 NZ	√	√	√	√	√	-	-	-	-	
		X 14 XE	√	√	√	√	√	-	√	√	-	
		X 16 SZR	√	√	√	√	√	-	√	√	-	
		X 16 XEL	√	√	√	√	√	-	√	√	-	

 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-F		X 18 XE	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	√	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-2E	√	√	√	√	√	-	-	-	-
			AF 13/14/20	√	√	√	-	-	-	-	-	-
		Transmission	AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
			Multi Info Display	√	√	√	-	-	-	-	-	-
		Infotainment System	Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
		Engine	X 12 XE	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	-	-
	X 16 SZR		√	√	√	√	√	-	√	√	-	
	X 16 XEL		√	√	√	√	√	-	√	-	-	
	X 17 DTL		√	√	√	√	√	-	√	-	-	
	X 18 XE1		√	√	√	√	√	-	√	-	-	
	X 20 DTL		√	√	√	√	√	-	√	-	-	
	X 20 XEV		√	√	√	√	√	-	-	-	-	
	Airbag SAB6		√	√	√	√	-	-	-	-	-	
	Anti Theft Warning		√	√	√	√	√	-	-	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-G	Body	Central Door Lock	√	√	√	√	√	-	-	-	-
			Engine Cooling Module	√	√	√	√	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-
		Infotainment System	Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Engine	12 NZ	√	√	√	√	√	-	-	-	-	
		C 12 NZ	√	√	√	-	-	-	-	-	-	
		C 14 NZ	√	√	√	√	√	-	-	-	-	
		C 14 SE	√	√	√	-	√	-	-	-	-	
		C 14 SEL	√	√	√	√	√	-	√	-	-	
		C 16 SEL	√	√	√	√	√	-	√	-	-	
		X 10 XE	√	√	√	√	√	-	√	√	-	
		X 10 XE S	√	√	√	-	-	-	-	-	-	

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-B		X 12 SZ	√	√	√	-	-	-	-	-	-
			X 12 XE	√	√	√	√	√	-	√	-	-
			X 14 SZ	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	√	-
			X 16 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
			AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
		Infotainment System	Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
	Engine	20 SE	√	√	√	√	-	-	-	-	-	
		X 20 DTH	√	√	√	√	√	-	√	-	-	
		X 20 SE	√	√	√	-	-	-	-	-	-	
		X 20 XEV	√	√	√	√	√	-	√	-	-	
		X 25 XE	√	√	√	√	-	-	-	-	-	
		X 30 XE	√	√	√	√	-	-	-	-	-	

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
1998	Omega-B	Body	Add On Heater	√	√	√	√	√	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	√	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Electronic Sun Roof	√	√	√	√	-	-	-	-	-
			Headlamp Levelling Device	√	√	√	√	√	-	√	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	√	-
			Seat Memory	√	√	√	-	-	-	-	-	-
		Chassis	ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			Height Control Module	√	√	√	-	-	-	-	-	-
			Servotronic	√	√	√	-	-	-	-	-	-
		Transmission	AR 25/35	√	√	√	√	√	-	-	-	-
		Infotainment System	Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCR 800	√	√	√	-	-	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
			16 LZ 2	√	√	√	√	√	-	-	-	-
			20 NEJ	√	√	√	√	-	-	-	-	-
			C 20 SEL	√	√	√	√	√	-	√	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automak er			Opel
									Softwar e			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identif ication	Read Codes	Erase Codes	Live Data	Actuato r Test	Program ming	Additio nal Function s	ECU Control	Others
	Vectra-B	Engine	C 22 SEL	√	√	√	√	√	-	√	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	√	-
			X 18 XE	√	√	√	√	√	-	√	-	-
			X 18 XE1	√	√	√	√	√	-	√	-	-
			X 20 DTH	√	√	√	√	√	-	√	-	-
			X 20 DTL	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	√	-	-
			X 25 XE	√	√	√	√	√	-	√	-	-
		Body	Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Instrument	√	√	√	-	-	-	-	-	-
			Immobiliser (KW82)	√	√	√	√	-	-	-	-	-
			Immobiliser (KWP)	√	√	√	√	-	-	-	-	-
		Chassis	ABS 415	√	√	√	√	-	-	-	-	-
			ABS 430	√	√	√	√	√	-	-	-	-
			ABS-5-TC	√	√	√	√	-	-	-	-	-
			ABS-5.3/5.4 (+TC)	√	√	√	√	√	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
Transmissi on	AF 13-II/17/20/22	√	√	√	√	√	-	√	-	-		
	AF 13II/20/22/30	√	√	√	√	√	-	-	-	-		
	Global Positioning System GPS	√	√	√	-	-	-	-	-	-		
	Info Display CART/CCRT	√	√	√	-	-	-	-	-	-		

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio 420	√	√	√	-	-	-	-	-	-
			Radio 435	√	√	√	-	-	-	-	-	-
			Radio 520	√	√	√	-	-	-	-	-	-
			Radio 620/635/635J	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CCRT 700	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Tigra	Engine	C 14 SEL	√	√	√	√	√	-	√	-	-
			C 16 SEL	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	√	-
			X 16 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
		Infotainment System	Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			25 TDS	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Frontera	Engine	X 20 SE	√	√	√	-	-	-	-	-	-
			X 22 XE	√	√	√	-	-	-	-	-	-
		Body	Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Central Door Lock	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
	Chassis	ABS 415	√	√	√	√	-	-	-	-	-	
	Monterey	Body	Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS 5	√	√	√	√	√	-	-	-	-
	Sintra	Engine	X 22 DTH	√	√	√	√	√	-	√	-	-
			X 22 XE	√	√	√	-	-	-	-	-	-
			X 30 XE	√	√	√	-	-	-	-	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
		Infotainment System	Multi Info Display	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
	Arena	Engine	F8Q (1.9l)	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-
		Body	Airbag AC4	-	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	-	-	-	-	-	-
			14 SE	√	√	√	√	√	-	-	-	-

FCAR 爱夫卡 FCAR F3 Diagnostic List									Automaker			Opel
									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Astra-F	Engine	16 LZ 2	√	√	√	√	√	-	-	-	-
			16 NZR	√	√	√	√	√	-	√	-	-
			18 SE	√	√	√	√	-	-	-	-	-
			C 14 NZ	√	√	√	√	√	-	-	-	-
			C 14 SE	√	√	√	√	√	-	-	-	-
			C 16 SE	√	√	√	√	√	-	-	-	-
			C 18 SEL	√	√	√	√	√	-	√	√	-
			X 14 NZ	√	√	√	√	√	-	-	-	-
			X 14 XE	√	√	√	√	√	-	√	√	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	√	-
			X 18 XE	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	√	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-2E	√	√	√	√	-	-	-	-	-
			Traction Control (TC)	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
			AF 13II/20/22/30	√	√	√	-	-	-	-	-	-
		Infotainment System	Multi Info Display	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
Radio CAR 500	√		√	√	√	√	-	-	-	-		
			12 NZ	√	√	√	√	√	-	-	-	-
			C 12 NZ	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Corsa-B	Engine	C 14 NZ	√	√	√	√	√	-	-	-	-
			C 14 SE	√	√	√	-	√	-	-	-	-
			X 10 XE	√	√	√	√	√	-	√	√	-
			X 10 XE S	√	√	√	-	-	-	-	-	-
			X 12 SZ	√	√	√	-	-	-	-	-	-
			X 14 SZ	√	√	√	√	√	-	√	-	-
			X 14 XE	√	√	√	√	√	-	√	√	-
			X 16 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-
			Electronic Power Steering	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
		Infotainment System	Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CAR 500	√	√	√	√	√	-	-	-	-
		Engine	20 SE	√	√	√	√	-	-	-	-	-
			X 20 SE	√	√	√	-	-	-	-	-	-
			X 20 XEV	√	√	√	√	√	-	-	-	-
			X 25 XE	√	√	√	√	-	-	-	-	-
			X 30 XE	√	√	√	√	-	-	-	-	-
			Airbag SAB6	√	√	√	√	-	-	-	-	-
			Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	√	√	-	-	-

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
1997	Omega-B	Body	Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Electronic Sun Roof	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Seat Memory	√	√	√	-	-	-	-	-	-
		Chassis	ABS-2SE (+TC)	√	√	√	√	-	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
			Servotronic	√	√	√	-	-	-	-	-	-
		Transmission	AR 25/35	√	√	√	√	-	-	-	-	-
		Infotainment System	Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
		Engine	16 LZ 2	√	√	√	√	√	-	-	-	-
			20 NEJ	√	√	√	√	-	-	-	-	-
			C 20 SEL	√	√	√	√	√	-	√	-	-
			X 16 SZR	√	√	√	√	√	-	√	√	-
			X 16 XEL	√	√	√	√	√	-	√	√	-
			X 18 XE	√	√	√	√	√	-	√	-	-
			X 20 DTL	√	√	√	√	√	-	√	-	-
			X 20 XEV	√	√	√	√	√	-	√	-	-
			X 25 XE	√	√	√	√	√	-	√	-	-
			Add On Heater	√	√	√	-	-	-	-	-	-
			Airbag	-	√	√	-	-	-	-	-	-

									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Vectra-B	Body	Airbag SAB6	√	√	√	√		-	-	-	-
			Anti Theft Warning	√	√	√	√	√	-	-	-	-
			Central Door Lock	√	√	√	√	√	-	-	-	-
			Electronic Climate Control	√	√	√	√	√	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
			Instrument	√	√	√	√	√	-	-	-	-
		Chassis	ABS 415	√	√	√	√	-	-	-	-	-
			ABS-5-TC	√	√	√	√	-	-	-	-	-
			Cruise Control	√	√	√	-	-	-	-	-	-
		Transmission	AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
		Infotainment System	Multi Info Display	√	√	√	√	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CCR 600	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
			Triple Info Display	√	√	√	√	-	-	-	-	-
	Tigra	Engine	X 14 XE	√	√	√	√	√	-	√	√	-
			X 16 XE	√	√	√	√	√	-	-	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	√	-	√	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-5.3	√	√	√	√	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
			Radio CAR 300	√	√	√	√	-	-	-	-	-

 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
		Infotainment System	Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CAR 500	√	√	√	√	√	-	-	-	-
	Calibra	Engine	X 20 XEV	√	√	√	√	√	-	√	-	-
			X 25 XE	√	√	√	√	-	-	-	-	-
		Body	Airbag-S	√	√	√	√	-	-	-	-	-
			Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Board Computer	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS-2E	√	√	√	-	-	-	-	-	-
			Traction Control (TC)	√	√	√	-	-	-	-	-	-
		Transmission	AF 13/14/20	√	√	√	-	-	-	-	-	-
			AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
	Frontera	Engine	25 TDS	√	√	√	√	√	-	-	-	-
			X 20 SE	√	√	√	-	-	-	-	-	-
			X 22 XE	√	√	√	-	-	-	-	-	-
		Body	Anti Theft Warning	√	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS 415	√	√	√	√	-	-	-	-	-
	Monterey	Body	Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	ABS 5	√	√	√	√	√	-	-	-	-
		Engine	X 22 XE	√	√	√	-	-	-	-	-	-
			X 30 XE	√	√	√	-	-	-	-	-	-
		Body	Airbag	-	√	√	-	-	-	-	-	-
			Immobiliser	√	√	√	√	-	-	-	-	-
		Chassis	Cruise Control	√	√	√	-	-	-	-	-	-

FCAR 爱夫卡									Automaker			Opel
FCAR F3 Diagnostic List									Software			V6.1
Menu			Function									
Series	Year	System	Sub System	ECU Identification	Read Codes	Erase Codes	Live Data	Actuator Test	Programming	Additional Functions	ECU Control	Others
	Sintra	Transmission	AF 13II/20/22/30	√	√	√	√	√	-	-	-	-
			Multi Info Display	√	√	√	-	-	-	-	-	-
		Infotainment System	Radio CAR 300	√	√	√	√	-	-	-	-	-
			Radio CAR 400	√	√	√	√	√	-	-	-	-
			Radio CDR 500	√	√	√	√	√	-	-	-	-
Remarks: √ means the system has this function - means not supported at this moment.												